

Зип Общепит
vsezip.ru
+7(812)987-08-81



CX140CP

Edition 20060905-

vsezip.ru

Зип Общепит
vsezip.ru
+7(812)987-08-81

This exploded view diagram illustrates the assembly of a refrigerator. The main components shown include the top panel (100), the main body (81), the door (10), and the internal shelving system (61, 76, 77, 71). The diagram is annotated with numerous numbered callouts (1-113) identifying individual parts such as screws, nuts, washers, and structural components. A detailed inset at the top right shows the internal wiring and compressor assembly, including the compressor (25), condenser coils (24), and various electrical components (26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113). The diagram is presented in a technical, exploded view format, showing the relative positions and assembly sequence of the parts.

Pos	Code	Description	Info
001	3178300	PLUG	15/12/2003-
002	3601350	RACK SUPPORT	15/12/2003-
003	3601360	RACK SUPPORT	15/12/2003-
004	60A3280	DOOR UNIT	03/02/2005-
005	60A2530	DOOR UNIT	15/12/2003-
006	60A2540	DOOR UNIT	15/12/2003-
007	30A6420	INTERMEDIATE PANEL	15/12/2003-
008	30A5280	INTERMEDIATE PANEL	15/12/2003-
009	30F1510	FRIDGE DOOR	03/02/2005-
010	30F1370	FRIDGE DOOR	15/12/2003-
011	30T4510	BOTTOM BRACKET	15/12/2003-
012	30T6760	INTERMED. BRACKET	15/12/2003-
013	30W3850	COND. TRAY	15/12/2003-
014	32A2200	POWER SUPPLY CABLE	15/12/2003-
015	32D0020	CABLE CLAMP Ø 4 - 12	15/12/2003-
016	32D0710	THREE-POLE CONNECTOR	15/12/2003-
017	32D0740	TERMINAL BOARD	15/12/2003-
018	32G0350	HEATING ELEMENT	15/12/2003-
019	32G1010	HEATING ELEMENT	15/12/2003-
020	32G3510	RESISTOR	15/12/2003-
021	32G2420	HEATING ELEMENT	15/12/2003-
022	32G3310	RESISTOR	23/02/2005-
023	32M1080	FAN	15/12/2003-
024	32M2510	FAN	15/12/2003-
025	32M7020	FAN MOTOR	04/02/2005-
026	32V1210	RELAY	15/12/2003-
027	32V1290	RELAY	15/12/2003-
028	32V1360	ENGINE CUTOUT	15/12/2003-
029	32V1420	CONDENSER	15/12/2003-
030	32V1450	ENGINE CUTO	15/12/2003-
031	32V1490	CONDENSER	15/12/2003-
032	32V3720	RELAY	15/12/2003-
033	32V8180	THERMOREGULATOR	15/12/2003-
034	32V8200	THERMOREGULATOR	15/12/2003-
035	32W3770	MICROSWITCH	15/12/2003-
036	32W3790	LIGHT	15/12/2003-
037	32W3800	LAMP-HOLDER	15/12/2003-
038	32W3850	humidity selection	15/12/2003-
039	32W3970	switch BIPOLAR SWITCH	15/12/2003-
040	32X0120	GROMMET Ø 21	15/12/2003-
041	32X0140	GROMMET Ø13,5-Ø25	15/12/2003-
042	32Z3470	TRANSFORMER	15/12/2003-
043	33A0180	FILTER	15/12/2003-
044	33A0510	DEFROST SOL. VALVE	15/12/2003-
045	33A1200	AUXIL.VALVE	15/12/2003-
046	34D4260	EVAPORATOR	15/12/2003-
047	34D6180	CONDEN.+BAFFLE	15/12/2003-
048	34D6390	COMPRESSOR R134a (TN)	15/12/2003-
049	34D6760	COMPRESSOR	15/12/2003-
050	34D7300	CONDENSER	15/12/2003-
051	34E0150	MOTOR UNIT	15/12/2003-

Pos	Code	Description	Info
052	34E0790	MOTOR UNIT	15/12/2003-
053	35L1090	CONTROL BOARD	15/12/2003-
054	35H4240	COMPONENT GUARD	20/02/2004-
055	35P3570	CLOSING PLATE	15/12/2003-
056	35P3620	CLOSING PLATE	15/12/2003-
057	3AQ0140	EVAPORATOR GUARD	15/12/2003-
059	35R9121	RACK	15/12/2003-
060	35R9131	RACK	15/12/2003-
061	35R9140	GUIDE	15/12/2003-
062	35R9260	LOCK SUPPORT	15/12/2003-
063	3065480	SUPPORT	05/09/2006-
064	35R9850	PROTECTION SUPPORT	15/12/2003-
065	35U4230	LOCK SUPPORT	15/12/2003-
066	35V1710	TRAY TRIM	15/12/2003-
067	35W0462	TRAY ASS.Y	15/12/2003-
068	35W4350	TRAY ASS.Y	15/12/2003-
070	35Y1680	BOTTOM BRACKET	15/12/2003-
071	35Y9391	RACK	19/07/2005-
072	35Y9381	RACK	19/07/2005-
073	35Y3090	LAMP GUARD	15/12/2003-
074	35Y3830	FAN SUPPORT	15/12/2003-
075	35Y5140	DRAIN GUARD	15/12/2003-
076	36A0710	GRID	15/12/2003-
077	36A4780	UNION GRID	15/12/2003-
078	36C2020	FAN GUARD	15/12/2003-
079	36C2031	FAN GUARD	15/12/2003-
080	36C5600	FOOT	15/12/2003-
081	36E4890	FRAME TRIM	15/12/2003-
082	36E2120	TOP BRACKET	15/12/2003-
083	36E2240	LAMP PROTECTION GLASS SLIDE	15/12/2003-
084	36E2270	CONDENS. DRAIN	15/12/2003-
085	36E2280	FRAME TRIM	15/12/2003-
086	36E4960	FRAME TRIM	15/12/2003-
087	36E4750	CONDENS. DRAIN	15/12/2003-
088	36E2420	FRAME TRIM	15/12/2003-
089	36E2510	CONDENS. DRAIN	15/12/2003-
090	36E3330	CONDENS. DRAIN	15/12/2003-
091	36G6520	HINGE	15/12/2003-
092	36M0080	LOCK U BOLT	15/12/2003-
093	36M0090	LOCK BRACKET	15/12/2003-
094	36M1380	LOCKING HOOK	15/12/2003-
095	36M7070	KEY LOCK	15/12/2003-
096	36M7080	HINGE	15/12/2003-
097	36Q1880	DRAIN PLUG	15/12/2003-
098	36Z2360	PLASTIC COATED TRAY	21/09/2004-
099	36Z1410	GASKET	15/12/2003-
100	36Z1530	COND. TRAY	15/12/2003-
101	37N5690	SILK-SCREE.PANEL	15/12/2003-
103	37Q5450	DOOR GASKET	15/12/2003-
104	37Q5460	DOOR GASKET	15/12/2003-
105	40K1626	BODY	15/12/2003-

Pos	Code	Description	Info
106	32V3730	NTC PROBE	15/12/2003-
107	35X1640	DRAIN TRAP	15/12/2003-
108	35Y9400	RACK	15/12/2003-
109	36M7660	RH GUIDE	21/09/2004-
110	36M7670	LH GUIDE	21/09/2004-
111	32V6010	EVAPORATOR PROBE NTC	15/12/2003-
112	35Y2000	SUPPORT	15/12/2003-
113	32M7020	FAN MOTOR	02/10/2004-