

Зип Общепит
vsezip.ru
+7(812)987-08-81



SM1L

Edition 20030916-

vsezip.ru

Зип Общепит
vsezip.ru
+7(812)987-08-81

This is a detailed exploded view diagram of a refrigerator, showing the main body (4), top panel (6), door (5), and various internal components like shelves (16), drawers (63), and the cooling system (44). The diagram includes numerous numbered callouts for individual parts, such as screws (e.g., 8, 11, 20), nuts (e.g., 38, 39), and specialized fasteners. A watermark for 'Зип Общепит' and 'vsezip.ru' is overlaid on the top half, along with a phone number '+7(812)987-08-81'.

Pos	Code	Description	Info
002	3178300	PLUG	01/07/1997-
004	30D5690	FRAME	15/10/1997-
005	30F0450	DOOR	01/07/1997-
005	30F0860	DOOR	26/10/2001-
006	6006280	TOP ASS. Y	01/07/1997-
007	30T2680	BOTTOM BRACKET	01/07/1997-
008	30T2690	BRACKET	01/07/1997-
009	30W4140	TRAY ASS.Y	14/01/2002-
011	36G9570	PIN	16/03/2001-
012	32A2160	POWER SUPPLY CABLE	01/07/1997-
013	32D0220	CABLE CLAMP Ø 16	01/07/1997-
014	32D0740	TERMINAL BOARD	01/07/1997-
015	32D1350	CABLE CLAMP	01/07/1997-
016	32G2020	HEATING ELEMENT	01/07/1997-
017	32M2260	FAN	11/06/2001-
018	32M5840	FAN MOTOR	11/06/2001-
019	32M6220	FAN	12/05/2000-
020	32W1890	MICROSWITCH	01/07/1997-
021	32X0120	GROMMET Ø 21	01/07/1997-
022	32X0220	FAIRLEAD	01/07/1997-
023	32V3050	ELECTRONIC CARD (NR. 2 DISPLAY	12/05/2001-
024	32V0441	PIN PROBE	12/05/2001-
025	32Z9250	SWITCH	01/07/1997-
026	32Z9500	FUSE-HOLDER	01/07/1997-
027	32Z9520	FUSE	01/07/1997-
028	32V3040	ELECTRONIC CARD	12/05/2001-
029	32V0150	TEMP. PROBE	12/05/2001-
030	60A2140	COMPRESSOR KIT	16/09/2003-
032	32V6140	CONDENSER	11/06/2001-
033	32Z9910	PRESSURE-SWITCH	01/07/1997-
034	32Z9920	CONDENSER	01/07/1997-
035	33A0280	THERMOST. VALVE	01/07/1997-
036	33A0840	BORE	04/09/1997-
037	33A0330	FILTER	01/07/1997-
038	33A1200	AUXIL.VALVE	01/07/1997-
039	33D0740	FLOW-ON LIGHT	01/07/1997-
040	33G0070	VALVE	01/07/1997-
041	33G1160	TRAY	15/05/2002-
042	33Q3370	ELBOW	01/07/1997-
043	34D8890	COMPRESSOR	11/06/2001-
044	34D4821	CONDEN.+BAFFLE	11/06/2001-
045	34D5220	EVAPORATOR	01/07/1997-
046	34D5330	MOTOR ASS.Y	01/07/1997-
046	34D9940	MOTOR ASS.Y	11/06/2001-
049	35C3760	RACK 3T NF	21/06/1999-
049	36C4020	LH RACK	15/11/1999-
050	35C5770	PANEL BOARD	01/07/1997-
051	3AA3660	EVAPORATOR GUARD	12/05/2000-
052	35C5830	GUIDE	01/07/1997-
053	35C6250	PROBE SUPPORT	01/07/1997-
054	35C7060	BRACKET PROT.	01/07/1997-

Pos	Code	Description	Info
055	35C7250	GUIDE	01/07/1997-
056	35C7560	"S"FRAME	01/07/1997-
058	35G3370	COVER	01/07/1997-
059	35S4540	"OMEGA" BRACKET	01/07/1997-
061	35X3860	DRAIN PIPE	07/05/1999-
062	36C2010	FAN GUARD	01/07/1997-
063	36C2390	TRIM FRAME	01/07/1997-
064	36C2401	TRIM FRAME	15/10/1997-
065	36C3690	ST-STEEL FO	21/12/2001-
065	36C4770	FOOT	14/01/2002-
066	36E1440	PROTECT GR	05/07/1999-
067	36C2750	SPACER	01/07/1997-
068	36D4440	PIN	01/07/1997-
070	36D9490	TOP BRACKET	01/07/1997-
073	36E0340	SPACER	12/05/2001-
074	36E0350	CABLE CAMP	01/07/1997-
075	36E0410	BUSHING	01/07/1997-
076	36G3940	PULLEY	01/07/1997-
077	36G6520	HINGE	01/07/1997-
078	36G8140	PIN	01/07/1997-
079	36G9560	HANDLE	16/03/2001-
080	3600770	SPACER	01/07/1997-
081	36Z0300	COND. TRAY	01/07/1997-
082	36Z1140	CARD PROTECTION	12/05/2001-
083	37N0470	SILK-SCREE.PANEL	12/05/2001-
084	37Q3810	GASKET	15/10/1997-
085	3AA3720	FRONT PANNEL	12/05/2001-
086	30G3710	PLUG	01/07/1997-
087	6013130	DOOR ASS.Y	01/07/1997-
087	6013320	DOOR ASS.Y	26/10/2001-
088	32Q4070	CABLE ASS.Y	01/07/1997-
089	32D0710	THREE-POLE CONNECTOR	16/05/1998-
091	35Y2280	SUPPORT	11/06/2001-
092	35P0440	TOP EVAP. HEAD	03/05/1999-
093	36Z0490	ENGINE CUTOUT	01/07/1997-
095	32Z2750	COIL	01/07/1997-
096	36C4010	RH RACK	15/11/1999-
097	33Q4390	COUPLING TUBES	12/11/1999-
098	36E2030	SPACER	12/05/2001-
099	34D7590	COOLER	11/06/2001-
100	33Q4800	COUPLING TUBES	11/06/2001-
101	35Y2550	PLATE	15/06/2001-
102	35Y3790	PROTECTION MOTOR	28/11/2001-
103	36A4830	COOLER	17/10/2002-