

Зип Общепит



Spare parts for:

vsezip.ru

Laundry machines (812) 987-08-81



Suitable for:

**PRIMUS**



This catalogue is automatically generated.  
Therefore, the sequence of the items might  
not be always shown at best.

Updates will be issued in case of additions  
and/or amendments.

*Suitable universal spare parts may not be included*

Rel. 2013-10170120






Suitable for:

**3786155 DOOR GASKET**  
for Dryer (POLIMATIC) T24 - T35  
for Dryer (PRIMUS) T24 - T35



PRIMUS 525107

**3786571 DOOR GASKET**  
ø 580 mm



PRIMUS RSPM406129

**3786142 DOOR GASKET ø 560 mm**  
for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
for Washing machine (PRIMUS) FS33 - FS40 - FS55  
for Washing machine (WHIRLPOOL) WACS35 - WACS45  
WACS55



PRIMUS F02107003214


PRIMUS 273115021915

# PRIMUS Общепит



Suitable for:

**3786156 DOOR GASKET**  
for Dryer (POLIMATIC) T11 - T13 - T16 - T9  
for Dryer (PRIMUS) T11 - T13 - T16 - T9



PRIMUS 519933

**3786154 DOOR GASKET ø 530 mm**  
for Washing machine (GRANDIMPIANTI) WR37  
for Washing machine (POLIMATIC) RS35  
for Washing machine (PRIMUS) RS35



PRIMUS R35108001814

PRIMUS 273112001766

**3186024 DOOR GLASS GASKET ø 325 mm**  
for Washing machine (GRANDIMPIANTI) WFM11 - WFM6  
WFM6S - WFM8 - WF11 - WF8 - WR11 - WR8  
for Washing machine (POLIMATIC) FS10 - FS6 - FS7  
P65 - P75 - RS10 - RS6 - RS7  
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6  
FS7 - F10 - F6 - F7 - P6 - P7 - RS10 - RS6  
RS7  
for Washing machine (WHIRLPOOL) LW100 - LW70  
WACS11 - WACS6 - WACS7 - WACS8 - WAC11 - WAC8



PRIMUS PRI503000004

+7(812)987-08-81

## 3186113 DOOR TANK GASKET

external  $\varnothing$  400 mm internal  $\varnothing$  270 mm  
 for Washing machine (DANUBE) GF11 - GF18 - GF8  
 for Washing machine (GRANDIMPIANTI) WFC8E - WFP6E  
 WF11 - WF18 - WF8 - WMC11000 - WMC6000  
 WMC8000  
 for Washing machine (IPSO) HF110 - HF165 - HF55  
 HF65 - HF76 - HF95 - HW131 - HW132 - HW164  
 HW165 - HW55 - HW64 - HW72 - HW75 - HW94  
 H132  
 for Washing machine (POLIMATIC) C6 - C8 - FS10  
 FS6 - FS7 - F10 - F6 - F7 - P65 - P75  
 for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6  
 FS7 - F10 - F16 - F6 - F7 - P6 - P7  
 for Washing machine (WHIRLPOOL) WACS11 - WACS17  
 WACS6 - WACS7 - WACS8




PRIMUS PRI505000045

PRIMUS 526344

## 3786432 TENSIONING STRIP

for gasket  
 for Washing machine (DANUBE) GF11 - GF18 - GF8  
 for Washing machine (GRANDIMPIANTI) WFC8E - WFP6E  
 WF11 - WF18 - WF8 - WMC11000 - WMC6000  
 WMC8000  
 for Washing machine (IPSO) HF55 - HW131 - HW164  
 HW64 - HW72 - HW75 - HW94  
 for Washing machine (PRIMUS) FS10 - FS7 - P6 - P7  
 for Washing machine (WHIRLPOOL) WACS11 - WACS6  
 WACS7 - WACS8



PRIMUS PRI185000112

## 3786568 EXTERNAL DOOR GASKET

for Dryer (ASKO) TDC44  
 for Dryer (IMESA) ES55 - ES75  
 for Dryer (PRIMUS) DAM5  
 for Dryer (WHIRLPOOL) AGB204 - AGB205 - AGB206  
 AGB207 - SACE5



PRIMUS 8061815

## 3786570 EYEHOLE GASKET

$\varnothing$  430 mm  
 for Washing machine (PRIMUS) FS16 - FS22 - LH165  
 RS13 - RS22  
 for Washing machine (WHIRLPOOL) LWS220



PRIMUS 273112994945

PRIMUS 529575

## 3186111 EYEHOLE GASKET $\varnothing$ 420 mm

for Washing machine (GRANDIMPIANTI) WMC17 - WMC23  
 WM17 - WM23 - WR18 - WR24  
 for Washing machine (PRIMUS) RS16 - RS22  
 for Washing machine (WHIRLPOOL) WAC17 - WAC23



PRIMUS PRI505000041

## 3786437 EYEHOLE GLASS GASKET

for Dryer (GIRBAU) SEI12  
 for Dryer (IPSO) DR25 - DR35  
 for Dryer (PRIMUS) DA11 - DA13 - DA15 - D14 - D25  
 for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE15  
 SACE17 - SACE25 - SWE131 - SWE140 - SWE151  
 SWE251



PRIMUS RSP70030901

PRIMUS RSP70211901



Suitable for:



**3786143 GASKET FOR DOOR GLASS ø 435 mm**  
 for Washing machine (GRANDIMPIANTI) WFM33 - WFM40 WFM55  
 for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
 for Washing machine (PRIMUS) FS33 - FS40 - FS55  
 for Washing machine (WHIRLPOOL) LWS330 - LWS440 LWS550




PRIMUS 273115021905

**3786415 GASKET FOR EYEHOLE**  
 for Washing machine (PRIMUS) F5 - P5  
 for Washing machine (WHIRLPOOL) LWS50



PRIMUS BLO0002401903

**3786419 GASKET FOR EYEHOLE**  
 for Washing machine (ASKO) WMC55  
 for Washing machine (IMESA) LM5 - WMC55  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB201 - AGB202 AGB203



PRIMUS 8064025

**3786427 GASKET FOR EYEHOLE**  
 for Dryer (GIRBAU) SE112  
 for Dryer (IPSO) DR25 - DR35  
 for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA25  
 for Dryer (WHIRLPOOL) DA11 - DA13 - DA15 - DA25 SACE11 - SACE13 - SACE17 - SWE111 - SWE131 SWE151 - SWE251



PRIMUS RSP70131601

PRIMUS RSP70211601

**3786572 LOWER GASKET**  
 length 425 x width 30 mm



PRIMUS 8061980

**3786573 SIDE GASKET**  
 length 490 x width 30 mm




PRIMUS 8061616

**3786575 TANK DOOR GASKET**



PRIMUS BLO002133500

**3786434 TANK GASKET - 12 HOLES**  
 for Washing machine (PRIMUS) P6 - P7 - RS10 - RS7  
 for Washing machine (WHIRLPOOL) WACS6 - WACS7 WAC11 - WAC8



PRIMUS PRI505000001

### 3063087 BEARING FOR TANK

for Washing machine (PRIMUS) F6 - RS6 - RS7  
for Washing machine (WHIRLPOOL) LWS70 - LW70  
WAC8



PRIMUS PRI608000004

PRIMUS ROULE6206


### 3063088 BEARING FOR TANK

for Washing machine (PRIMUS) LWS100 - LWS70  
LV100 - LW70 - RS7 - WAC11 - WAC17  
for Washing machine (WHIRLPOOL) F10 - F6 - F7  
RS10 - RS16 - RS6 - WAC8



PRIMUS PRI608000002


### 3063094 BEARING HOLDER PLATE 6204



PRIMUS RSP70013901

### 3063044 BEARING 3305A 2RS

for PRIMUS WASHING MACHINE P7-C8  
for POLIMATIC WASHING MACHINE P75  
for Washing machine (POLIMATIC) P75  
for Washing machine (PRIMUS) C8 - P7  
for Washing machine (WHIRLPOOL) WACS7



PRIMUS 510904

### 3063045 BEARING 3307A 2RS


for Washing machine (POLIMATIC) P75  
for Washing machine (PRIMUS) C8 - P7  
for Washing machine (WHIRLPOOL) LWS160 - WACS7  
WAC17



PRIMUS 510903

### 3063048 BEARING 6209 2Z

for Washing machine (DOMUS) DFI9 - W10 - W9  
for Washing machine (FAGOR) LA-10M - LB-10M - LC-8  
LF-8  
for Washing machine (PRIMUS) F10 - F7 - RS10  
RS16  
for Washing machine (WHIRLPOOL) LWS100 - LW100  
WAC11 - WAC17



PRIMUS PRI608000067

### 3063093 BEARING 6306 2RS

for Washing machine (PRIMUS) F5 - P5  
for Washing machine (WHIRLPOOL) LWS50 - LWS51




PRIMUS BLO0008003000

PRIMUS BLO00080030000

### 3063002 BEARING 6307 2RS

for Washing machine (POLIMATIC) FS10 - FS6 - FS7  
P65 - RS13  
for Washing machine (PRIMUS) C6 - FS10 - FS6 - FS7  
P5 - P6 - RS13  
for Washing machine (WHIRLPOOL) LWS51 - WACS11  
WACS6 - WACS8  
for Washing machine (ZANUSSI)



PRIMUS BLO0008003100

PRIMUS BLO00080031000


PRIMUS PRI608001048



Suitable for:

**3063013 BEARING 6310 2Z**

for Washing machine (DANUBE) GF23 - GF26  
for Washing machine (GIRBAU) HS6017 - WR23 - WR26  
for Washing machine (GRANDIMPIANTI) GF23 - GF26 - WR26  
for Washing machine (IPSO) WFF135 - WFF150  
WFF165 - WFF185 - WFF235 - WF135 - WF150  
WF165 - WF185 - WF235  
for Washing machine (MARENO) FM12 - FM18E - FM18G  
FM18V - FM8  
for Washing machine (POLIMATIC) FS16 - RS18 - RS22  
for Washing machine (PRIMUS) FS16 - RS18 - RS22  
for Washing machine (WHIRLPOOL) LWS160 - WACS17  
WAC17/23



PRIMUS PRI608002048

# PRIMUS Общепит



Suitable for:

**5044505 BEARING 6312 2RS1**

for Washing machine (PRIMUS) F22 - WACS17




PRIMUS PRI608000080

+7(812)987-08-81

**3063108 KIT PIN FOR DRUM**

for Dryer (GIRBAU) SEI12  
for Dryer (IPSO) DR25 - DR35  
for Dryer (PRIMUS) DA11 - DA13 - DA15  
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17  
SWE111 - SWE131 - SWE151



PRIMUS RSP70244701P

PRIMUS 70244701P


**5044504 ROLLER BEARING NU2215 ECP**

for Washing machine (PRIMUS) F22 - WACS17



PRIMUS PRI608000079

**3063095 SPACER**



PRIMUS RSP430352

**3063106 WHEEL FOR BASKET SUPPORT**

for Dryer (IMESA) ES5  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB205 - AGB207 - SACES



PRIMUS 8052622

## Belts

**3062087 BELT IMESA A 049**



PRIMUS RSP70298701

**5042708 BELT XPZ 1950LW**

for Washing machine (IPSO) WE234 - WE245



PRIMUS PRI607000072

**3062064 BELT 0209Y09B17 2350 mm**  
 length 2375 mm  
 for DRYER DANUBE DD8  
 for DRYER FAGOR SE/7  
 for DRYER IPSO DD8  
 for DRYER GIRBAU SDE7  
 for DRYER PRIMUS D9-DA9-DAM/S9  
 for DRYER WHIRLPOOL SACE8-SACE86-SACE8T-SWE90-SWE290-SWE390-SW91-SW291-SW391  
 for Dryer (DANUBE) DD8  
 for Dryer (FAGOR) S/E-7  
 for Dryer (GIRBAU) SDE7  
 for Dryer (IPSO) DD8  
 for Dryer (PRIMUS) DAM/S9 - DA9 - D9  
 for Dryer (WHIRLPOOL) SACE8 - SACE8C - SACE8T  
 SWE290 - SWE291 - SWE390 - SWE391 - SWE90

**3062022 MULTIGRIP BELT J 1209 H12 4 GROOVES**  
 for Washing machine (ASKO) WMC55 - WMP55  
 for Washing machine (GRANDIMPIANTI) WFEC5  
 for Washing machine (IMESA) LM5  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB200 - AGB201  
 AGB202 - AGB203



PRIMUS RSP510178

PRIMUS RSP511255P

PRIMUS RSP591174

PRIMUS 8061682

**3062032 MULTIGRIP BELT J 1549 H14 5 GROOVES**  
 for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S  
 for Washing machine (POLIMATIC) P65 - P75 - RS10  
 RS6 - RS7  
 for Washing machine (PRIMUS) P6 - P7 - RS10 - RS6  
 RS7  
 for Washing machine (WHIRLPOOL) WACS6 - WACS7  
 WAC11 - WAC23 - WAC8

**3062023 MULTIGRIP BELT 7PH 1970 H11 6 GROOVES**  
 with belt tightening spring kit  
 for Dryer (ASKO) TDC44 - TD33  
 for Dryer (IMESA) ES5  
 for Dryer (PRIMUS) DAM5  
 for Dryer (WHIRLPOOL) AGB204 - AGB205 - AGB206  
 AGB207 - SACE5



PRIMUS 509940

PRIMUS 8061961

PRIMUS 8065710

PRIMUS 8801267

**3062067 SMOOTH BELT V TT138**  
 for Dryer (PRIMUS) D15 - D25 - D35  
 for Dryer (WHIRLPOOL) SACE25 - SWE150 - SW25

**3062066 TOOTHED BELT MULTI V J8 1165**  
 for Dryer (PRIMUS) D15  
 for Dryer (WHIRLPOOL) SWE150



PRIMUS RSPM401182

PRIMUS RSP56095

**3062071 TOOTHED BELT POLY V 1150J**  
 for Dryer (PRIMUS) D14 - D15 - D25 - D35  
 for Dryer (WHIRLPOOL) SACE25 - SWE150 - SW25



PRIMUS RSPM411425



Suitable for:

**3062069 TOOTHED BELT POLY V 2391 J**

for Dryer (GIRBAU) ST112  
for Dryer (IPSO) DR25  
for Dryer (PRIMUS) DA11 - DA13  
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SWE111  
SWE131



PRIMUS RSP70053105

# PRIMUS Общепит



Suitable for:

**3053552 BELT TENSIONING ROLLER**

7(812)987-08-81

vsezip.ru



PRIMUS RSP70050401

PRIMUS 70050401

**3062065 TOOTHED BELT POLY V 2606J**

for Dryer (IPSO) DR35  
for Dryer (PRIMUS) DA15  
for Dryer (WHIRLPOOL) SACE17 - SWE151



PRIMUS RSP70053104

**3053552 BELT TENSIONING ROLLER**



PRIMUS RSP70050401

PRIMUS 70050401

**3062098 TOOTHED BELT SPZ 1562 LW**



PRIMUS PRI607000093

**3062111 TOOTHED BELT SPZ 2037**



PRIMUS COURROIEXP2030

PRIMUS PRI607000099

**3062106 TOOTHED BELT SPZX 1512**

for Washing machine (AGA) 520/16



PRIMUS PRI607000110

**5041457 TOOTHED BELT TM M406386 DF**

height 12 mm - length 1600 mm  
for Dryer (PRIMUS) D14  
for Dryer (WHIRLPOOL) SWE140



PRIMUS RSPM406386

**3062036 TOOTHED BELT XPA 2650**

for double-motor machines  
for Washing machine (POLIMATIC) FS40 - FS55  
for Washing machine (PRIMUS) FS40 - FS55



PRIMUS PRI607000095

PRIMUS 272111002650

**3062035 TOOTHED BELT XPA 2582**

for single-motor machines  
for Washing machine (GRANDIMPIANTI) WFM40 - WFM55  
for Washing machine (POLIMATIC) FS40 - FS55  
for Washing machine (PRIMUS) FS40 - FS55



PRIMUS 503526

PRIMUS 529776



**3062031 TOOTHED BELT XPZ 1000**  
 for double-motor machines  
 for Washing machine (GRANDIMPIANTI) WM40000  
 for Washing machine (IPSO) HF205  
 for Washing machine (POLIMATIC) FS40 - FS55  
 for Washing machine (PRIMUS) FS40 - FS55



PRIMUS PRI607000096

PRIMUS 272111001000

**3062105 TOOTHED BELT XPZ 1137 LW**



PRIMUS PRI607000092

**3062024 TOOTHED BELT XPZ 1587**  
 for Washing machine (GRANDIMPIANTI) WFM11  
 for Washing machine (POLIMATIC) FS6  
 for Washing machine (PRIMUS) FS6  
 for Washing machine (WHIRLPOOL) WACS11



PRIMUS 101175

**3062070 TOOTHED BELT XPZ 1600**  
 width 9mm



PRIMUS COURR1575

PRIMUS PRI607000075

PRIMUS 102350

**3062107 TOOTHED BELT XPZ 2160**



PRIMUS 272111002160

**3062109 TOOTHED BELT XPZ 2187**



PRIMUS COURR2187XPZ

PRIMUS PRI607000070

**3062034 TOOTHED BELT XPZ 2280**  
 for double-motor machines  
 for Washing machine (POLIMATIC) FS33  
 for Washing machine (PRIMUS) FS33



PRIMUS PRI607000065

**3062033 TOOTHED BELT XPZ 2360**  
 for single-motor machines  
 for Washing machine (GRANDIMPIANTI) WFM33  
 for Washing machine (POLIMATIC) FS33  
 for Washing machine (PRIMUS) FS33



PRIMUS 515454

**3062037 TOOTHED BELT XPZ 987**  
 for double-motor machines  
 for Washing machine (POLIMATIC) FS33  
 for Washing machine (PRIMUS) FS33



PRIMUS PRI607000080

**3062068 V TOOTHED BELT 5PJ1956**  
 for Dryer (PRIMUS) D5  
 for Dryer (WHIRLPOOL) SWE50 - SWE51



PRIMUS BLO2603700

vsezip.ru +7(812)987-08-81



Suitable for:

### 3062110 V-BELT XPZ 1320

for Washing machine (PRIMUS) F22 - F22S  
for Washing machine (WHIRLPOOL) LWS220 - WAC23



PRIMUS PRI607000085

# PRIMUS Общепит



Suitable for:


## vsezip.ru

# +7(812)987-08-81

## Castors

### 3062080 WHEEL FOR MANIFOLD

for Dryer (DANUBE) DD8  
for Dryer (GIRBAU) SE/7  
for Dryer (IPSO) DD8  
for Dryer (PRIMUS) DAM9 - DA9  
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291  
SWE90



PRIMUS RSP510708P

### 3062084 CLAMP



PRIMUS RSP23748

### 3062075 AXIS

for pulley



PRIMUS RSP56461

PRIMUS RSP56461P

### 3062082 WASHER

for Dryer (DANUBE) DD8  
for Dryer (FAGOR) SE/7  
for Dryer (GIRBAU) SDE7  
for Dryer (IPSO) DD8  
for Dryer (PRIMUS) DAM/S9 - DA9 - D9  
for Dryer (WHIRLPOOL) SACE8 - SACE8T - SACE86  
SWE290 - SWE390 - SWE90 - SW291 - SW391 - SW91



PRIMUS RSP52549

## Circlips

### 3391029 CLAMP

for bearing



PRIMUS PRI242000008

### 3391030 CLAMP

for bearing  
for Washing machine (POLIMATIC) RS10 - RS16  
for Washing machine (PRIMUS) F10 - F7 - RS10  
RS16  
for Washing machine (WHIRLPOOL) LWS100 - LW100  
WAC11 - WAC17



PRIMUS PRI242000009



Suitable for:

3002010 SEEGER RING



PRIMUS 307732030080

PRIMUS Общепит



Suitable for:

3002011 SEEGER RING ø 100 mm



PRIMUS 307732030100

## Contact thermostats

3744089 CONTACT THERMOSTAT FOR ELEMENT



PRIMUS BLO001406000

PRIMUS BLO01406000

3744090 CONTACT THERMOSTAT FOR ELEMENT



PRIMUS RSPM401404

5041552 CONTACT THERMOSTAT L340-50F 140°C


for Dryer (GIRBAU) SEI12  
for Dryer (IPSO) DR25 - DR35  
for Dryer (PRIMUS) DA11 - DA13 - DA15 - D14  
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17  
SWE111 - SWE131 - SWE151



PRIMUS RSPM409433

3744038 CONTACT THERMOSTAT 150° C

mounting distance 40 mm  
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
ES5EIE  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE  
SE5IC - SE5IE



PRIMUS 8008487

3744033 SAFETY THERMOSTAT

for Dryer (FAGOR) S/E-7  
for Dryer (GIRBAU) SE7  
for Dryer (IPSO) DD8  
for Dryer (PRIMUS) DAM9 - DA9  
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291  
SWE390 - SWE391 - SWE90 - SWE91



PRIMUS RSP510183

PRIMUS RSP511412

PRIMUS RSP62600

3744035 SAFETY THERMOSTAT

for Dryer (GIRBAU) SEI12  
for Dryer (IPSO) DR25 - DR35  
for Dryer (PRIMUS) DA11 - DA13 - DA15  
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17  
SWE111 - SWE131 - SWE151



PRIMUS RSPM411307



Suitable for:

**3744037 SAFETY THERMOSTAT**

for Dryer (GIRBAU) SE112  
for Dryer (IPSO) DR25 - DR35  
for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25  
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17  
SACE25 - SWE111 - SWE131 - SWE151 - SWE250



PRIMUS RSPM410220

**3744076 SAFETY THERMOSTAT KIT 350°C**

for Dryer (PRIMUS) D25  
for Dryer (WHIRLPOOL) SACE25 - SWE250



PRIMUS M4347P3

PRIMUS RSPM4347P3

**5054352 SAFETY THERMOSTAT 230°C**

for Dryer (PRIMUS) T11 - T13 - T24 - T9



PRIMUS 514127

# PRIMUS Общепит



Suitable for:

**5043418 SAFETY THERMOSTAT**


for Dryer (PRIMUS) D14  
for Dryer (WHIRLPOOL) SWE140



PRIMUS RSPM406413

**3744036 SAFETY THERMOSTAT 225°C**

for Dryer (FAGOR) S/E-7  
for Dryer (GIRBAU) SE7  
for Dryer (IPSO) DD8  
for Dryer (PRIMUS) DAM9 - DA9  
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE390  
SWE90 - SWE91



PRIMUS RSP510701

PRIMUS RSP62641

**3744029 SAFETY THERMOSTAT 300°C**

for Dryer (PRIMUS)  
for Dryer (WHIRLPOOL)



PRIMUS RSP56082

## Contactors

**3454025 CONTACTOR MOD. LC1 D32**

for heating 220-230V-50Hz-7.5Kw  
for Washing machine (GRANDIMPIANTI) WFP120  
for Washing machine (PRIMUS) FS10 - FS120 - FS16  
FS23 - FS7 - MB140 - MB180 - MB26 - MB33  
MB44 - MB66 - MB90 - RS10 - RS16 - RS22 - RS7  
XS22  
for Washing machine (WHIRLPOOL) WACS11 - WACS17  
WACS28AE - WACS28AV - WACS35AE - WACS35AV  
WACS46AE - WACS46AV - WACS70AE - WACS70AV  
WACS8 - WAC11 - WAC17 - WAC23 - WAC8




PRIMUS PRI345002019

PRIMUS 345002019

**3454024 CONTACTOR 4S - MOD. TP3250**

'16A 250V - 10A 400V  
'50/60Hz  
for Dryer (ASKO) TDC44  
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
ES5EIE  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE  
SE5IC - SE5IE



PRIMUS 8009148

PRIMUS 8064179



Suitable for:

**3454027 3-PHASE CONTACTOR**

for motor 24V-2.2Kw  
for Dryer (PRIMUS) DA11 - DA13 - DA15  
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17  
SWE111 - SWE131 - SWE151



PRIMUS RSPM413614

PRIMUS Общепит



Suitable for:

vsezip.ru

+7(812)987-08-81

**Door catches**

**3242625 DOOR HOOK**

for Washing machine (PRIMUS) P5  
for Washing machine (WHIRLPOOL) LWS51M



PRIMUS BLO0005407800

**3242638 HOOK PRESSURE SPRING**



PRIMUS BLO0008126400

PRIMUS BLO0008126400

**3242637 PLASTIC FINGER**


for hook



PRIMUS BLO0003851300

**7104461 MECHANICAL DOOR LOCK**

for Dryer (PRIMUS) T24



PRIMUS 514530

**7104465 LOCK PLATE**

for Dryer (PRIMUS) T24



PRIMUS 524366



Suitable for:

# PRIMUS Общепит



Suitable for:

## Drain hoses

**3450165 CONNECTION SLEEVE**  
total length 150 mm  
internal ø 110 mm



PRIMUS 101076

**5045876 DRAIN PIPE**  
length 65 mm  
for Washing machine (GRANDIMPIANTI) WFM8 - WF8 WR8  
for Washing machine (PRIMUS) F6 - F7 - RS6 - RS7  
for Washing machine (WHIRLPOOL) LW70 - WACS8 WAC8



PRIMUS 101044

**3450164 SLEEVE**  
overall length 170 mm



PRIMUS PRI540000032

PRIMUS PRI540000032

## Drain tanks

**3527013 TANK FOR CONDENSATE**  
for Dryer (ASKO) TDC44  
for Dryer (IMESA) ES5  
for Dryer (WHIRLPOOL) AGB205 - AGB207



PRIMUS 8061941

**3527014 INJECTOR FOR TANK**  
for Dryer (ASKO) TDC44  
for Dryer (IMESA) ES5  
for Dryer (WHIRLPOOL) AGB205 - AGB207



PRIMUS 8053077

## Electrical gas valves and accessories

**7104436 GAS VALVE HONEYWELL VR4605AB1027 230V**  
for DRIER PRIMUS T24




PRIMUS 102000

+7(812)987-08-81

### 3121020 COMPLETE DOOR LOCK WITHOUT DELAYER


for Washing machine (GRANDIMPIANTI) WFM11 - WFM18  
WFM8 - WF18E  
for Washing machine (POLIMATIC) FS16 - FS22 - FS23  
FS23PR  
for Washing machine (PRIMUS) FS16 - FS22 - FS23  
FS23PRO  
for Washing machine (WHIRLPOOL) 016004-WACS17



PRIMUS 509473

### 3242633 COMPLETE LOCK 220V

for washing machine Whirlpool 7.5 KG  
mod. WACS8 - 016002 - 10 kg mod. WACS11 016003  
Primus 7.5 kg mod. FS7 - 10 kg mod. FS10



PRIMUS PRI610060077

PRIMUS 528054


### 3242626 KEY LOCK PIN

placed in the locks



PRIMUS PRI610000134


### 3242636 COMPLETE LOCK 220V



PRIMUS PRI610057077

### 3803013 DOOR CONTACT

110-240V  
for lock mod.682-P10



PRIMUS PRI346000003

PRIMUS 34600003

### 3240777 MICROSWITCH 8A 250V


for Washing machine (GRANDIMPIANTI) WFM11 - WFM18  
WFM8 - WR11 - WR18 - WR24 - WR37 - WR8  
for Washing machine (POLIMATIC) FS10 - FS16 - FS23  
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18  
RS22 - RS27 - RS35 - RS6 - RS7  
for Washing machine (PRIMUS) FS10 - FS16 - FS23  
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18  
RS22 - RS27 - RS35 - RS6 - RS7  
for Washing machine (WHIRLPOOL) 016002-WACS8  
016003-WACS11 - 016013-WAC8 - 016014-WAC11  
016015-WAC17 - 016016-WAC23



PRIMUS PRI610032077

### 3242652 CONTROL ARM

for lock




PRIMUS PRI610000135



Suitable for:

**3803013 DOOR CONTACT**  
110-240V  
for lock mod.682-P10



PRIMUS PRI346000003


PRIMUS 34600003

**3240777 MICROSWITCH 8A 250V**  
for Washing machine (GRANDIMPIANTI) WFM11 - WFM18  
WFM8 - WR11 - WR18 - WR24 - WR37 - WR8  
for Washing machine (POLIMATIC) FS10 - FS16 - FS23  
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18  
RS22 - RS27 - RS35 - RS6 - RS7  
for Washing machine (PRIMUS) FS10 - FS16 - FS23  
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18  
RS22 - RS27 - RS35 - RS6 - RS7  
for Washing machine (WHIRLPOOL) 016002-WACS8  
016003-WACS11 - 016013-WAC8 - 016014-WAC11  
016015-WAC17 - 016016-WAC23



PRIMUS PRI610032077

**3242631 DOOR LOCK**



PRIMUS 8061679

**5041476 DOOR LOCK STRIKE**  
for WASHING MACHINE ASKO WMC55  
for WASHING MACHINE IMESA LM5P  
for WASHING MACHINE PRIMUS PW5  
for WASHING MACHINE WHIRLPOOL AGB200-201-202-203



PRIMUS ASK8061798

# PRIMUS Общепит



Suitable for:

**3242626 KEY LOCK PIN**  
placed in the locks

## +7(812)987-08-81



PRIMUS PRI610000134

**3803015 DOOR LOCK CONTACT**  
for Washing machine (IMESA) LM5EGDP - LM5EGDV  
LM5EIDP - LM5EIDV  
for Washing machine (PRIMUS) PW5  
for Washing machine (WHIRLPOOL) AGB200/WP  
AGB201/WP - AGB202/WP - AGB203/WP



PRIMUS 8061680



## 3121022 DOOR LOCK 220/240V 50Hz

for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S  
 for Washing machine (MIELE)  
 for Washing machine (POLIMATIC) P65 - P75  
 for Washing machine (PRIMUS) C6 - C8 - MB16 - MB16.6  
 MB33 - MB44 - MB66 - P6 - P7  
 for Washing machine (WHIRLPOOL) 016017-WACS28AE  
 016018-WACS28AV - 016019-WACS35AE  
 016020-WACS35AV - 016021-WACS46AE  
 016022-WACS46AV - 016023-WACS70AE  
 016024-WACS70AV



PRIMUS PRI61000075

## 3121023 DOOR OPENING ELECTROMAGNET 205V

for Washing machine (GRANDIMPIANTI) WFM11 - WFM18  
 WFM8 - WR11 - WR18 - WR24 - WR37 - WR8  
 for Washing machine (POLIMATIC) FS10 - FS16 - FS23  
 FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18  
 RS22 - RS27 - RS35 - RS6 - RS7 - XS22  
 for Washing machine (PRIMUS) FS10 - FS16 - FS23  
 FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18  
 RS22 - RS27 - RS35 - RS6 - RS7 - XS22



PRIMUS PRI610012077

## 3121024 DOOR OPENING ELECTROMAGNET 205V

for Washing machine (GRANDIMPIANTI) WFM33 - WFM40  
 WFM55  
 for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
 for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02117001814

## 3242648 MAGNET FOR DOOR

for door lock



PRIMUS 8061878

## 3242651 MAGNET SUPPORT 60 x 27 mm



PRIMUS 8061886

## Electronic boxes

## 3091038 FLAME CONTROLLER MOD.MICRO56N24

24V - 50/60Hz  
 for Dryer (WHIRLPOOL) SWE140



PRIMUS RSPM413433

PRIMUS RSP70367401P



Suitable for:




Suitable for:

## Electronic printed-circuit boards

### 5048147 CONTROLLER BOARD


for Washing machine (PRIMUS) FS10 - FS16 - FS23  
FS33 - FS40 - FS55 - FS6 - FS7 - WACS8



PRIMUS 526008

### 7104466 ELECTRIC PLATE WITH DISPLAY

for Dryer (PRIMUS) T24



PRIMUS 102459

### 7104452 LCD SCREEN PROTECTION RUBBERPIECE


for Dryer (PRIMUS) T24



PRIMUS 101275

### 3390284 ELECTRONIC BOARD

for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25  
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17  
SACE25 - SWE111 - SWE131 - SWE151 - SWE250




PRIMUS RSPM413498P

PRIMUS RSPM513498

PRIMUS RSP70228401P

### 7104499 CONTROL PUSH-BUTTON PANEL


for Dryer (PRIMUS) T24



PRIMUS 547081

### 3322328 CONTROL KEYBOARD

OPL electronic control  
for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25  
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17  
SACE25 - SWE111 - SWE131 - SWE151




PRIMUS RSP70115801

+7(812)987-08-81

## 3390301 ELECTRONIC BOARD MCB FC

for Washing machine (PRIMUS) FS10 - FS16 - FS22  
 FS33 - FS40 - FS55 - FS6 - FS7 - MB16 - MB26  
 MB33 - MB44 - MB66 - RS10 - RS13 - RS16 - RS18  
 RS22 - RS27 - RS35 - RS6 - RS7 - XS22 - XS35  
 XS43  
 for Washing machine (WHIRLPOOL) LWS220 - WACS11  
 WACS16AE - WACS17 - WACS23 - WACS28AE  
 WACS28AV - WACS35 - WACS35AE - WACS35AV  
 WACS42 - WACS46AE - WACS46AV - WACS55  
 WACS70AE - WACS70AV - WACS8 - WAC11 - WAC17  
 WAC23 - WAC8



PRIMUS 100986

PRIMUS 516696

## 3322230 CONTROL KEYBOARD MCB LC

for Washing machine (PRIMUS) FS10 - FS16 - FS22  
 FS33 - FS40 - FS55 - FS6 - FS7 - MB16 - MB26  
 MB33 - MB44 - MB66 - RS10 - RS13 - RS16 - RS18  
 RS22 - RS27 - RS35 - RS6 - RS7 - XS22 - XS35  
 XS43  
 for Washing machine (WHIRLPOOL) LWS220 - WACS11  
 WACS16A - WACS17 - WACS23 - WACS28A - WACS28AE  
 WACS28AV - WACS35A - WACS35AE - WACS35AV  
 WACS42 - WACS46A - WACS46AE - WACS46AV  
 WACS55 - WACS70A - WACS70AE - WACS70AV - WACS8  
 WAC11 - WAC17 - WAC23 - WAC8



PRIMUS 100521

## 3390283 ELECTRONIC POWER BOARD

for Dryer (ASKO) TDC44  
 for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
 ES5EIE  
 for Dryer (PRIMUS) DAM5  
 for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
 AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE  
 SE5IC - SE5IE



PRIMUS 8077348

## 3340065 MOTOR CONTROL UNIT

for Washing machine (ASKO) WMC55  
 for Washing machine (IMESA) LM5 - LM5EGDP  
 LM5EGDV - LM5EIDP - LM5EIDV  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP  
 AGB201 - AGB201/WP - AGB202 - AGB202/WP  
 AGB203 - AGB203/WP - WACS5 - WES5GP - WES5GV  
 WES5IP - WES5IV



PRIMUS 8061399

## 3390336 POWER ELECTRONIC BOARD mod. EL 101K



PRIMUS 745895

PRIMUS 771985008277

## 3390282 POWER SUPPLY BOARD PWR

for Washing machine (PRIMUS) C6 - C8 - FS10 - FS16  
 FS7 - RS10 - RS13 - RS16 - RS18 - RS22 - RS27  
 RS35 - RS6 - RS7  
 for Washing machine (WHIRLPOOL) WACS11 - WACS17  
 WACS8 - WAC11 - WAC17 - WAC23 - WAC8



PRIMUS PRI343000212

PRIMUS 516694

## 3319718 KEY BOARD EASY CONTROL




PRIMUS PRI348000123



Suitable for:

**3322327 PROGRAMMER MCBLC**

for Washing machine (PRIMUS) FS10 - FS16 - FS7  
P6 - P7 - RS10 - RS16 - RS22 - RS7  
for Washing machine (WHIRLPOOL) WACS11 - WACS17  
WACS8 - WAC11 - WAC17 - WAC23 - WAC8



PRIMUS 100984

PRIMUS 516695


# PRIMUS Общепит



Suitable for:

**7104444 TEMPOORIZATION PLATE**

for Washing machine (PRIMUS) FS10 - FS6 - FS7  
WACS8 - W10




PRIMUS 526004

+7(812)987-08-81

## Filters

**3160492 COMPLETE FILTER SUPPORT**



PRIMUS 8061811

PRIMUS 80797500

**3786569 FILTER HOLDER GASKET**



PRIMUS 8065274

**3160433 FILTER**  
for Dryer (PRIMUS) D9  
for Dryer (WHIRLPOOL) SWE90



PRIMUS RSP500025

PRIMUS RSP502140


PRIMUS RSP502140PV

**3160436 FILTER**  
for Dryer (ASKO) TDC44  
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
ES5EIE  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE  
SE5IC - SE5IE



PRIMUS 8061812

**3123129 FILTER FOR CONDENSER**  
length 360 mm/width.240 mm  
for Dryer (ASKO) TDC44  
for Dryer (IMESA) ES5EGC  
for Dryer (PRIMUS) DAMC5  
for Dryer (WHIRLPOOL) AGB205 - SACE5



PRIMUS 8063752

**3160428 FILTER 510 x 510 mm**



PRIMUS RSPM400523



Suitable for:

**3160430 FILTER 610 x 610 mm**  
for Dryer (PRIMUS) D14 - D25  
for Dryer (WHIRLPOOL) SACE25 - SWE250  
for Washing machine (GIRBAU) SMI12E



PRIMUS RSPM400522

PRIMUS Общепит



Suitable for:


**3160429 FILTER 620 x 620 mm**  
for Dryer (IPSO) DR25 - DR35  
for Dryer (PRIMUS) DA11 - DA13 - DA15  
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE15  
SWE111 - SWE131 - SWE151



PRIMUS RSP70019201

PRIMUS RSP70229101

**3160493 GAUZE FILTER**



PRIMUS RSP503980

**3160494 PILE FILTER**



PRIMUS BLO0003831601

## Gaskets and seals

**3786440 COPPER GASKET 14x20x2 mm STUFFING GLAND**



PRIMUS PRI524000001

PRIMUS PRI52400001

**3786566 FELT GASKET**

for Dryer (IPSO) DR25 - DR35  
for Dryer (PRIMUS) DA11 - DA13 - DA15  
for Dryer (WHIRLPOOL) BWE111 - SWE111 - SWE131



PRIMUS 70066002

**3786429 FELT STRIP**

ø 470 mm  
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
ES5EIE  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
AGB206/WP - AGB207/WP - SACE5



PRIMUS 8052649

**3391028 FELT STRIP CLAMP**

for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC  
ES5EIE  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205  
AGB205/WP - AGB206 - AGB206/WP - AGB207  
AGB207/WP - SACE5



PRIMUS 8055054



Suitable for:

**3786431 GASKET FOR MANIFOLD**


ext.ø 410 mm - int.ø 380 mm  
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
ES5EIE - ES55 - ES75  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205  
AGB205/WP - AGB206 - AGB206/WP - AGB207  
AGB207/WP - SACE5



PRIMUS 8061821

**5043175 RING SUPPORT GASKET**

for WASHING MACHINE PRIMUS FS16



PRIMUS F01104000514

PRIMUS PRI505002042

**3786439 SPACER GASKET**



PRIMUS RSP70193801

**3212012 CHAIN TENSIONING PINION**



PRIMUS RSPM401369

# PRIMUS Общепит



Suitable for:

**3786433 MANIFOLD GASKET**

SWE350-SWE91-SWE291-SWE391  
for Dryer (FAGOR) SE-7  
for Dryer (GIRBAU) SE/7  
for Dryer (ILSO) DD8  
for Dryer (PRIMUS) DA9 - D9  
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291  
SWE390 - SWE391 - SWE90 - SWE91



PRIMUS RSP501801

PRIMUS RSP510207

**3786418 SELF ADHESIVE FELT SHIM**


length 47 mm  
for Dryer (PRIMUS) DA9  
for Dryer (WHIRLPOOL) 016025-SACE8



PRIMUS RSP501121

PRIMUS RSP58049

**3786574 TANK GASKET ø 630 mm**



PRIMUS PRI505010001

## Gears

**7102433 TRANSMISSION CHAIN**

for Dryer (PRIMUS) D14 - SWE140  
for Dryer (WHIRLPOOL) SWE140



PRIMUS RSPM401425



Suitable for:

# PRIMUS Общепит



Suitable for:

## Glasses

7104435 DOOR GLASS ø 725 mm

for DRIER PRIMUS T24

5047834 DOOR GLASS

for WASHING MACHINE WFEC 5  
for WASHING MACHINE PRIMUS PW5

# +7(812)987-08-81



PRIMUS ASK8061685



PRIMUS 512052

3520012 FRONT DOOR GLASS

for Washing machine (PRIMUS) FS10 - FS7 - P6 - P7  
for Washing machine (WHIRLPOOL) WACS11 - WACS6  
WACS7 - WACS8



PRIMUS PRI505000044

## Handles

3242504 DOOR HANDLE

for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02107300024

3242505 DOOR HANDLE PIN

for Washing machine (GRANDIMPIANTI) WFM33 - WFM40  
WFM55  
for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02107500014

3242506 PIN BUSHING FOR DOOR HANDLE

ø external 20 mm - ø internal 14 - height 20 mm  
for Washing machine (GRANDIMPIANTI) WFM33 - WFM40  
WFM55  
for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS 323622641243

3242507 SCREW BUSHING FOR DOOR HANDLE

ø external 30 mm - ø internal 18 mm - height 45 mm  
for Washing machine (GRANDIMPIANTI) WFM33 - WFM40  
WFM55  
for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02107002315



Suitable for:

**3242493 SHAFT CAM**

for Washing machine (GRANDIMPIANTI) WFM33 - WFM40  
WFM55  
for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
for Washing machine (PRIMUS) FS33 - FS40 - FS55

**PRIMUS** Общепит

Suitable for:

**vsezip.ru**

**77(812)987-08-81**



PRIMUS F02117001214

**3242715 DOOR HANDLE**



PRIMUS RSP503646

**3453020 DRUM PLATE**

for Dryer (FAGOR) SE-7  
for Dryer (GIRBAU) SE7  
for Dryer (IPSO) DD8  
for Dryer (PRIMUS) DA9 - D9  
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291  
SWE390 - SWE391 - SWE90 - SWE91




PRIMUS RSP501676

PRIMUS RSP510187

**3453025 BRACKET**

for Dryer (FAGOR) SE-7  
for Dryer (GIRBAU) SE7  
for Dryer (IPSO) DD8  
for Dryer (PRIMUS) DA9 - D9  
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291  
SWE390 - SWE391 - SWE90 - SWE91



PRIMUS RSP501554

**3242649 ROLL HOLDER - 10 PCS**

for Dryer (IMESA) DAM5 - ES5EGC - ES5EGE - ES5EIC  
ES5EIE  
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE  
SE5IC - SE5IE



PRIMUS 8061953-33



## 3242491 ROUND DOOR HANDLE

for Washing machine (POLIMATIC) FS10 - FS16 - FS23  
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS6 - RS7  
for Washing machine (PRIMUS) FS10 - FS16 - FS23  
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS6 - RS7



PRIMUS PRI610011085

## 3242492 BACKING SPRING

for Washing machine (GRANDIMPIANTI) WFM18 - WFM22  
WR11 - WR18 - WR24 - WR37 - WR8  
for Washing machine (POLIMATIC) FS10 - FS16 - FS23  
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18  
RS22 - RS27 - RS6 - RS7 - XS22  
for Washing machine (PRIMUS) FS10 - FS16 - FS23  
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18  
RS22 - RS27 - RS6 - RS7 - XS22



PRIMUS PRI611000045

## 3242490 HANDLE FIXING PLATE

for GRANDIMPIANTI WASHING MACHINE  
WFM18-WFM22-WR8  
WR11-WR37  
for PRIMUS WASHING MACHINE RS6-RS7-RS10-RS13-RS18  
RS22-RS27-FS6-FS7-FS10-FS16-FS23-FS23PRO-XS22  
for POLIMATIC WASHING MACHINE RS6-RS7-RS10-RS13  
RS18-RS22-RS27-FS6-FS7-FS10-FS16-FS23-FS23PRO-XS22




PRIMUS PRI610000082

PRIMUS 223107300013

## 3242499 ALUMINIUM HANDLE FOR ROUND DOOR

for Washing machine (GRANDIMPIANTI) WFM11 - WFM18  
WFM8  
for Washing machine (POLIMATIC) FS10 - FS16 - FS23  
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18  
RS22 - RS6 - RS7  
for Washing machine (PRIMUS) FS10 - FS16 - FS23  
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18  
RS22 - RS6 - RS7



PRIMUS 100219

## 3242508 FIXING PLATE

ø 10 mm - length 64 mm  
for Washing machine (GRANDIMPIANTI) WFM11 - WFM18  
WFM22 - WFM8 - WR11 - WR18 - WR24 - WR37 - WR8  
for Washing machine (POLIMATIC) RS10 - RS13 - RS18  
RS22 - RS27 - RS6 - RS7  
for Washing machine (PRIMUS) RS10 - RS13 - RS18  
RS22 - RS27 - RS6 - RS7



PRIMUS PRI610000089



Suitable for:



Suitable for:

+7(812)980-08-81

### 3355869 HEATING ELEMENT PROTECTION

flange 80x22 mm  
 for Washing machine (IMESA) LM18  
 for Washing machine (POLIMATIC) FS10 - FS16 - FS23  
 FS23PRO - FS33 - FS40 - FS55 - FS6 - FS7 - P65  
 P75 - RS13 - RS27 - RS35  
 for Washing machine (PRIMUS) FS10 - FS16 - FS23  
 FS23PRO - FS33 - FS40 - FS55 - FS6 - FS7  
 MB26 - MB33 - MB44 - MB66 - P6 - P7 - RS13  
 RS27 - RS35  
 for Washing machine (WHIRLPOOL) WACS11 - WACS28AE  
 WACS28AV - WACS35 - WACS35AE - WACS35AV  
 WACS42 - WACS46AE - WACS46AV - WACS55 - WACS6  
 WACS7 - WACS70AE - WACS70AV - WACS8 - WAC11  
 WAC17 - WAC23 - WAC8



PRIMUS PRI342001016

### 3455344 HEATING ELEMENT GROUP WITH KLIXONS

2400W 400V  
 for Dryer (PRIMUS) D15  
 for Dryer (WHIRLPOOL) SWE51 - SWE51M



PRIMUS BLO0001622500

### 3455260 HEATING ELEMENT 10 KW

length 500 mm  
 for Dryer (PRIMUS) D25  
 for Dryer (WHIRLPOOL) SACE25 - SWE250



PRIMUS RSPM410941

### 3455262 HEATING ELEMENT 1000 W - 230 V

blue and red  
 overall length 265 mm - width 30 mm  
 for Washing machine (ASKO) WMC55  
 for Washing machine (IMESA) LM5 - LM5EGDP  
 LM5EGDV - LM5EIDP - LM5EIDV  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP  
 AGB201 - AGB201/WP - AGB202 - AGB202/WP  
 AGB203 - AGB203/WP - WACS5



PRIMUS 8061704

### 3355868 HEATING ELEMENT 2x2000W 230V

length 470 mm - width 65 mm  
 flange 82x28 mm  
 for Washing machine (GRANDIMPIANTI) WFM18 - WFM33  
 WR18 - WR24  
 for Washing machine (POLIMATIC) FS10 - FS16 - FS33  
 FS6 - FS7 - RS10 - RS13 - RS27 - RS35 - RS6  
 RS7  
 for Washing machine (PRIMUS) FS10 - FS16 - FS33  
 FS6 - FS7 - RS10 - RS13 - RS16 - RS22 - RS27  
 RS35 - RS6 - RS7  
 for Washing machine (WHIRLPOOL) WACS17 - WAC17  
 WAC23



PRIMUS PRI342000027

PRIMUS PRI342030027

### 3355873 HEATING ELEMENT 2000W 230V

length 260 mm - width 65 mm  
 flange 80x28 mm  
 for Washing machine (FAGOR) LAC-7 - LC-7 - LC/AC-7  
 LC/E-7 - LF-7  
 for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S  
 WFM8 - WR11 - WR37 - WR8  
 for Washing machine (POLIMATIC) FS10 - FS6 - FS7  
 P65 - P75 - RS10 - RS13 - RS6 - RS7  
 for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6  
 FS7 - F10 - F6 - F7 - P6 - P7 - RS10 - RS13  
 RS6 - RS7  
 for Washing machine (WHIRLPOOL) LSW100 - LWS70  
 WACS11 - WACS6 - WACS7 - WACS8 - WAC11 - WAC8



PRIMUS PRI342000011

**3455263 HEATING ELEMENT 2000W 230V**

white and red  
 overall length 355 mm - width 30 mm  
 flange 54x27 mm  
 for WASHING MACHINE ASKO WMC55  
 for WASHING MACHINE IMESA LM5  
 for WASHING MACHINE PRIMUS PW5  
 for WASHING MACHINE WHIRLPOOL AGB200 A 203-WAC55  
 for Washing machine (ASKO) WMC55  
 for Washing machine (IMESA) LM5 - LM5EGDP  
 LM5EGDV - LM5EIDP - LM5EIDV  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP  
 AGB201 - AGB201/WP - AGB202 - AGB202/WP  
 AGB203 - AGB203/WP - WAC55



PRIMUS 8061703

**3355892 HEATING ELEMENT 2750W 230V**


length 270 mm - width 65 mm  
 flange 81x28 mm  
 for Washing machine (POLIMATIC) P65 - P75  
 for Washing machine (PRIMUS) P6 - P7



PRIMUS 100383

**3355894 HEATING ELEMENT 4500W 230/400V**

dimensions 360x90x50 mm  
 for Dryer (IPSO) CD165 - CD220 - CD350  
 for Dryer (POLIMATIC) T11 - T13 - T16 - T24 - T35  
 T9  
 for Dryer (PRIMUS) T11 - T13 - T16 - T24 - T35  
 T9




PRIMUS 510985

Suitable for:

**3455264 HEATING ELEMENT 2500W 230V CONDENSER**

for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
 ES5EIE  
 for Dryer (PRIMUS) DAM/C5  
 for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
 AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE  
 SE5IC - SE5IE - 016064 - 016066



PRIMUS 8063808

**3455257 HEATING ELEMENT 4000W 220V**

for Dryer (GIRBAU) SE112  
 for Dryer (IPSO) DR25  
 for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA25  
 for Dryer (WHIRLPOOL) SACE11 - SWE111



PRIMUS RSP70034415

PRIMUS RSP70034416

**3455265 HEATING ELEMENT 4500W 380V**

for DRIER FAGOR SE-7  
 for DRIER GIRBAU SE7-SDE7  
 for DRIER PRIMUS DA9-D9  
 for DRIER WHIRLPOOL SACE8-SWE90-SWE290-  
 SWE390-SWE91-SWE291-SWE391  
 for Dryer (DANUBE) TD8  
 for Dryer (FAGOR) SE-7  
 for Dryer (GIRBAU) SDE7 - SE7  
 for Dryer (PRIMUS) DA9 - D8 - D9  
 for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291  
 SWE390 - SWE391 - SWE90 - SWE91



PRIMUS PRI342100053

PRIMUS RSPS11014



Suitable for:

# PRIMUS Общепит



**5041537 HEATING ELEMENT 6000W 220V**  
 length 350 mm - flange 95x65 mm  
 for DRIER PRIMUS D14-DE14-SWE140  
 for DRIER WHIRLPOOL AGB204 A 207-SACES



PRIMUS RSPM410946


**3355874 HEATING ELEMENT 6000W 230V**  
 length 475 mm- width 65 mm  
 flange 80x28 mm  
 for Washing machine (GRANDIMPIANTI) WFM40 - WFM55  
 for Washing machine (POLIMATIC) FS16 - FS23  
 FS23PRO - FS40 - FS55 - RS27 - RS35 - XS22  
 for Washing machine (PRIMUS) FS16 - FS23 - FS23PRO  
 FS40 - FS55 - MB44 - MB66 - RS16 - RS22 - RS27  
 RS35 - XS22  
 for Washing machine (WHIRLPOOL) WACS17 - WACS42  
 WACS46AE - WACS46AV - WACS55 - WACS70  
 WACS70AE - WACS70AV - WAC17 - WAC23



PRIMUS PRI342000032


PRIMUS 540132

**3455252 HEATING ELEMENT 7000W 240V**  
 for DRIER PRIMUS D25  
 for DRIER WHIRLPOOL SWE250-SACE25  
 for Dryer (PRIMUS) D25  
 for Dryer (WHIRLPOOL) SACE25 - SWE250



PRIMUS RSPM405253

**3355893 HEATING ELEMENT 6000W 230/400V**  
 dimensions 360x90x50 mm  
 for Dryer (IPSO) CD165 - CD220 - CD350  
 for Dryer (POLIMATIC) T11 - T13 - T16 - T24 - T35  
 for Dryer (PRIMUS) T11 - T13 - T16 - T24 - T35  
 T9



PRIMUS 510984

**3455256 HEATING ELEMENT 7000W 230V**  
 for Dryer (IPSO) DR35  
 for Dryer (PRIMUS) DA13  
 for Dryer (WHIRLPOOL) SACE13 - SWE111



PRIMUS RSP70034402

PRIMUS RSP70034403

PRIMUS 70034402

**3455255 HEATING ELEMENT 8000W 220V**  
 length 50 mm  
 flange 95x54 mm  
 for DRIER PRIMUS DA15  
 for DRIER WHIRLPOOL SWE151-SACE17  
 for Dryer (PRIMUS) DA15  
 for Dryer (WHIRLPOOL) SACE17 - SWE151



PRIMUS RSP70034405

PRIMUS RSP70034406

## 3455261 HEATING ELEMENTS SET 4500 W 380 V

with contactor and klixon  
for Dryer (FAGOR) SE-7  
for Dryer (GIRBAU) SDE7 - SE7  
for Dryer (PRIMUS) DA9 - D9  
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291  
SWE390 - SWE391 - SWE90 - SWE91



PRIMUS PRI342000053

PRIMUS 102730

## 3355870 HEATING ELEMENT 3000W 230V

length 265 mm - width 65 mm  
flange 80x28 mm  
for Washing machine (AGA) SUPER25 - SUPER33  
for Washing machine (FA GOR) LAC-10 - LC-10  
LC/E-10 - LF-10  
for Washing machine (GRANDIMPIANTI) WFM11 - WR37  
for Washing machine (POLIMATIC) FS10 - FS6 - FS7  
P5 - P6 - P65 - P75 - RS10 - RS13 - RS18  
RS22 - RS6 - RS7  
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6  
FS7 - F6 - F7 - P6 - P7 - RS10 - RS13 - RS16  
RS18 - RS22 - RS6 - RS7  
for Washing machine (WHIRLPOOL) LSW100 - LWS70  
WACS11 - WACS6 - WACS7 - WACS8 - WAC11 - WAC17  
WAC23 - WAC8



PRIMUS PRI342000028

PRIMUS 540128

## Hinges

### 3053486 COMPLETE HINGE

for round door  
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6  
FS7 - F10 - F6 - F8 - P6 - P7  
for Washing machine (WHIRLPOOL) FS16 - LWS70  
LW100 - RS16 - SR22 - WACS11 - WACS17 - WACS6  
WACS7 - WACS8



PRIMUS 500080

### 3053494 HINGE FLAP



PRIMUS PRI610000126

### 3053490 COMPLETE HINGE


for corner door  
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS16  
FS6 - FS7 - F10 - F6 - F8 - P6 - P7 - RS16  
SR22  
for Washing machine (WHIRLPOOL) LWS70 - LW100  
WACS11 - WACS17 - WACS6 - WACS7 - WACS8



PRIMUS PRI155014019

PRIMUS 101377

### 3053494 HINGE FLAP



PRIMUS PRI610000126



Suitable for:

**3053484 COMPLETE TOP HINGE**

for dryer door 5 kg  
for Dryer (ASKO) TDC44  
for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC - ES5EIE - RS5EGC  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205 - AGB205/WP - AGB206 - AGB206/WP - AGB207 - AGB207/WP - SACE5



PRIMUS 8101803-26

**3053485 COMPLETE BOTTOM HINGE**

for dryer door 5 kg  
for Dryer (ASKO) TDC44  
for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC - ES5EIE  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205 - AGB205/WP - AGB206 - AGB206/WP - AGB207 - AGB207/WP - SACE5




PRIMUS 8061807-26

**3053546 DOOR HINGE**



PRIMUS 8061686-42

**3053487 HINGE**  
for Washing machine (PRIMUS) P5  
for Washing machine (WHIRLPOOL) LWS51M



PRIMUS BLO0005326400



Suitable for:

**3053491 BEARING FOR HINGE**

for Dryer (ASKO) TDC44  
for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC - ES5EIE  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205 - AGB205/WP - AGB206 - AGB206/WP - AGB207 - AGB207/WP - SACE5



PRIMUS 8061865-33

**3053550 HINGE PIN**  
ø 5 x length 135 mm



PRIMUS 8061687

**3053492 AXIS**  
for hinge



PRIMUS BLO0004131702



Suitable for:

3053551 HINGE PIN



PRIMUS PRI610010126

PRIMUS Общепит



Suitable for:

vsezip.ru

+7(812)987-08-81

## Interference suppression filters

3454019 TRAP CAPACITOR 0.47μF - 16A- 275V

50/60 Hz

for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC

ES5EIE

for Dryer (PRIMUS) DAM5

for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP

AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE

SE5IC - SE5IE

for Washing machine (IMESA) LM5EGDP - LM5EGDV

LM5EIDP - LM5EIDV

for Washing machine (PRIMUS) PW5

for Washing machine (WHIRLPOOL) AGB200/WP

AGB201/WP - AGB202/WP - AGB203/WP - WACS5

WACS5M - WES5GP - WES5GV - WES5IP - WES5IV



PRIMUS 8058558

## Ironmongery (screws,nuts,washers)

3063099 NUT


for bearing



PRIMUS RSPM412986

3063098

WASHER FOR BEARING



PRIMUS RSPM400991

## Lamps

3221598 LAMP BUSHING

for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC

ES5EIE

for Dryer (PRIMUS) DAM5

for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP

AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE

SE5IC - SE5IE



PRIMUS 8061887

3221597

LAMP SUPPORT

for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC

ES5EIE

for Dryer (PRIMUS) DAM5

for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP

AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE

SE5IC - SE5IE



PRIMUS 8061932



Suitable for:

**3221596 WHITE INDICATOR LIGHT**  
220 V -  $\varnothing$  13 mm



PRIMUS PRI349000032

PRIMUS PRI349000032

# PRIMUS Общепит



Suitable for:

## vsezip.ru

### +7(812)987-08-81

## Microswitches

### 3803021 DOOR MAGNETIC CONTACT

for product dispenser  
for Washing machine (PRIMUS) MB16 - MB26 - MB33  
MB44 - MB66  
for Washing machine (WHIRLPOOL) 016017-WACS28AE  
016018-WACS28AV - 016019-WACS35AE  
016020-WACS35AV - 016021-WACS46AE  
016022-WACS46AV - 016023-WACS70AE  
016024-WACS70AV



PRIMUS PRI346000030

PRIMUS PRI346000030

### 3803014 DOOR MICRO CONTACT

5A - 250 V  
for Dryer (PRIMUS) DA11 - DA17  
for Dryer (WHIRLPOOL) 016028-SACE11  
016032-SACE17



PRIMUS RSP70125101

PRIMUS RSR70125101

### 3803016 DOOR MICRO CONTACT

10 A - 250 V  
for Dryer (PRIMUS) DA11 - DA13 - DA15  
for Dryer (WHIRLPOOL) SACE13 - 016028-SACE11  
016032-SACE17




PRIMUS RSP70107001

PRIMUS RSR70107001

### 3803011 DOOR SAFETY DEVICE

for Washing machine (PRIMUS) P5  
for Washing machine (WHIRLPOOL) LWS51



PRIMUS BLO001727000

### 3803012 MICRO SWITCH


5 A - 250 V  
for Dryer (IMESA) ES5EGC - ES5EIC  
for Dryer (WHIRLPOOL) AGB205/WP - AGB207/WP  
016066-SE5GC - 016066-SE5IC



PRIMUS 8052643

### 3803023 FLOAT FOR MICRO SWITCH $\varnothing$ 45 mm

for Dryer (IMESA) ES5EGC - ES5EIC  
for Dryer (WHIRLPOOL) AGB205/WP - AGB207/WP  
016066-SE5GC - 016066-SE5IC



PRIMUS 8053056



## 3803020 MICRO SWITCH

0.1 A - 250 V  
for Washing machine (PRIMUS) P6 - P7  
for Washing machine (WHIRLPOOL) 016001-WACS6  
016071-WACS7



PRIMUS PRI610028077

## 3803022 MICRO SWITCH SET

for Dryer (PRIMUS) DA13



PRIMUS EXRSP70267301  
PRIMUS RSP70267301+...

PRIMUS RSP70266201+...  
PRIMUS RSP70270901P

PRIMUS RSP70266301+...

+7(812)987-08-81

## 3803044 MICROSWITCH




PRIMUS BLO0001725101

PRIMUS BLO001725101

## 3803046 MICROSWITCH DOOR 3SE4 300

16(4) A - 380 V



PRIMUS BLO001706600

PRIMUS BLO1706600

## 7104456 MICROSWITCH U83161.3 4A 250V



PRIMUS 517484

## 3240795 MICROSWITCH 10A 250V

for Washing machine (GIRBAU) HS5008 - HS6008  
HS6017  
for Washing machine (PRIMUS) DAMS9



PRIMUS RSP504570

## 3240778 MICROSWITCH 12A 250V

for Washing machine (GRANDIMPIANTI) WFM33 - WFM40  
WFM55  
for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02117002114

## 1240014 MICROSWITCH 16A 250V

for Washing machine (GRANDIMPIANTI) WFM33 - WFM40  
WFM55  
for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02117002224

PRIMUS G.R.CRO831613AR



Suitable for:

# PRIMUS Общепит




Suitable for:

## 3240136 MICROSWITCH 16A 250V

for Washing machine (DOMUS) DFI27 - W10  
 for Washing machine (FAGOR) LA-10M - LA-13M  
 LA-18M - LA-25M - LB-10M - LB-13M - LB-18M  
 for Washing machine (GRANDIMPIANTI) WFEC18 - WFEC6 - WFEC8 - WFP50 - WFP63 - WF11  
 WF18 - WF23 - WF26 - WF33 - WF8 - WR11 - WR18  
 WR26 - WR33 - WR8  
 for Washing machine (IPSO) HC100 - HC135 - HC165  
 HC60 - HC65 - HC75 - HF110 - HF132 - HF145  
 HF150 - HF165 - HF176 - HF185 - HF205 - HF235  
 HF245 - HF304 - HF450 - HF55 - HF570 - HF65  
 HF75 - HF95 - HW131 - HW164 - HW55 - HW64  
 HW72 - HW94 - WE110 - WE132 - WE165 - WE176  
 WE181 - WE234 - WE245 - WE304 - WE55 - WE73  
 WE95 - WFF100 - WFF135 - WFF150 - WFF165

# vsezip.ru

# +7(812)987-08-81



PRIMUS 8053107

## Motors

### 3340031 MOTOR AHV


2-42-P-09 380 HZ / 250V  
 max room temperature 60°C  
 for Washing machine (PRIMUS) P6 - P7  
 for Washing machine (WHIRLPOOL) WACS6 - WACS7



PRIMUS 102035

### 3340026 MOTOR AND MOTOR CONTROL BOARD SET

mod. AHV 2-42-P-09 - 0-380  
 380 HZ / 250V  
 for Washing machine (PRIMUS) P6 - P7  
 for Washing machine (WHIRLPOOL) WACS6 - WACS7  
 WAC17 - WAC8



PRIMUS 509820

### 3340122 MOTOR JQA48T17D11001AP 1/4HP 60Hz

TS.80.S4.4000 - 0256014  
 for Dryer (PRIMUS) DA13 - D11  
 for Dryer (WHIRLPOOL) SWE111 - SWE131



PRIMUS RSP70062802

### 3340067 MOTOR LM5

for Washing machine (ASKO) WMC55  
 for Washing machine (IMESA) LM5 - LM5EGDP  
 LM5EGDV - LM5EIDP - LM5EIDV  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP  
 AGB201 - AGB201/WP - AGB202 - AGB202/WP  
 AGB203 - AGB203/WP - WES5GP - WES5GV - WES5IP  
 WES5IV



PRIMUS 8063734


**3340117 MOTOR WEG AL80-04 THREE-PHASE**  
 0.75Kw 230/400V 50Hz 2.97/1.71A  
 1400 motor revolutions  
 for Washing machine (PRIMUS) FS6 - FS7  
 for Washing machine (WHIRLPOOL) WACS8



PRIMUS PRI32000012



**7104470 MOTOR 220/230V-380/415V**  
 power 0.65/0.55kW  
 rpm 720/430  
 axle ø 24x60 mm  
 for Washing machine (PRIMUS) F22 - F33



PRIMUS PRI325001037

**7104473 MOTOR 220/230V-380/415V 3000W**  
 WEG type 100L-04  
 motor revolutions 1410  
 for Washing machine (PRIMUS) F22



PRIMUS 338400100032

**7104472 MOTOR 220/380V 1500W**  
 shaft ø 24x54 mm  
 for Washing machine (PRIMUS) FS10 - WACS11



PRIMUS PRI32000013

**7104471 MOTOR 220/380V 2200W**  
 WEG type AL100L-04  
 motor revolutions 1410  
 for Washing machine (PRIMUS) FS16



PRIMUS PRI32000009

**3340032 SINGLE-PHASE CONVEYOR MOTOR SC5**  
 220 / 240 V - 50 Hz - 1425 rev./min  
 for Dryer (GIRBAU) SE12  
 for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA17  
 DA25  
 for Dryer (WHIRLPOOL) SACG11 - SACG13 - SACG15  
 SACG17 - SWG111 - SWG131 - SWG151



PRIMUS RSP70171601

**3340033 SINGLE-PHASE MOTOR**  
 220 V - 50 Hz - 1425 rev./min  
 for Dryer (FAGOR) SE-7  
 for Dryer (GIRBAU) SE7  
 for Dryer (PRIMUS) DA9 - D9  
 for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291  
 SWE390 - SWE391 - SWE90 - SWE91



PRIMUS RSP501212

PRIMUS RSP505843P


vsezip.ru  
 +7(812)987-08-81



Suitable for:

### 3340029 SINGLE-PHASE MOTOR VENTILATOR

220/240 V - 8  $\mu$ F - 50 Hz  
2850 RPM - 1.1 A - 270 W  
for Dryer (IMESA) ES5EGC - ES5EIC  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB204 - AGB205/WP  
AGB207/WP - SE5GC - SE5IC



PRIMUS 8061824

### 3340037 MOTOR VENTILATOR IMPELLER

ø 115 mm - thickness 43 mm




PRIMUS 8055200

PRIMUS 8065305

### 3340028 THREE-PHASE MOTOR HANING

230/400 V - 50 Hz  
for Washing machine (PRIMUS) F10 - RS10  
for Washing machine (WHIRLPOOL) LW100 - WAC11



PRIMUS PRI32000063

# PRIMUS Общепит



Suitable for:

### 3340038 FRONT FAN FOR MOTOR VENTILATOR

ø 115 mm / thickness 53 mm



PRIMUS 8061960

### 3340036 MOTOR VENTILATOR REAR CASE



PRIMUS 8052636

## Outlet solenoid valves and accessories

### 3120299 DRAIN SOLENOID VALVE MDB-0-2

normally OPEN - 220/240V 50/60Hz 24AMP  
inlet ø 50 mm - outlet ø 50 mm  
for Washing machine (FAGOR) LC/AC-7 - LC/E-10  
LC/E-14 - LC/E-7



PRIMUS ASK8008365

### 3120146 DRAIN SOLENOID VALVE MDB-0-3RA

normally OPEN - 230V 50/60Hz 18AMP  
inlet ø 76 mm - outlet ø 78 mm  
for Washing machine (GRANDIMPIANTI) WFM11 - WFM18  
WFM22 - WFM33 - WFM40 - WFM55 - WFM8 - WF11  
WF18 - WF8  
for Washing machine (POLIMATIC) FS10 - FS23  
FS23PRO - FS33 - FS40 - FS55 - FS6 - FS7  
RS10 - RS13 - RS18 - RS22 - RS27 - RS35 - RS6  
RS7 - XS22  
for Washing machine (PRIMUS) FS10 - FS23 - FS23PRO  
FS33 - FS40 - FS55 - FS6 - FS7 - RS10 - RS13  
RS18 - RS22 - RS27 - RS35 - RS6 - RS7 - XS22  
for Washing machine (WHIRLPOOL) 016002-WACS11  
016004-WACS17



PRIMUS PRI340055051

PRIMUS 101014



Suitable for:

**3120295 DRAIN SOLENOID VALVE MDP-0-2RA**

normally OPEN - 220/240V 50/60Hz 24AMP  
inlet  $\varnothing$  50 mm - outlet  $\varnothing$  50 mm  
for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S  
for Washing machine (POLIMATIC) P65 - P75  
for Washing machine (PRIMUS) P6 - P7



PRIMUS 101783

# PRIMUS Общепит



Suitable for:

**3248144 DRAIN VALVE COUPLING**

for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S  
for Washing machine (POLIMATIC) P65 - P75  
for Washing machine (PRIMUS) C6 - C8 - P6 - P7  
for Washing machine (WHIRLPOOL) WACS6 - WACS7



PRIMUS 101750

## Pins

**3324033 PIN**  
 $\varnothing$  380 mm



PRIMUS RSP70017701

## Portholes


**5027105 COMPLETE WASHING MACHINE DOOR**  
external  $\varnothing$  350 mm  
for Washing machine (IMESA) LM5



PRIMUS 8061650-42

PRIMUS 8064906-85

**5041476 DOOR LOCK STRIKE**  
for WASHING MACHINE ASKO WMC55  
for WASHING MACHINE IMESA LM5P  
for WASHING MACHINE PRIMUS PW5  
for WASHING MACHINE WHIRLPOOL AGB200-201-202-203



PRIMUS ASK8061798

**3386037 FRONT DOOR**  
for Washing machine (PRIMUS) P6 - P7



PRIMUS 500087



Suitable for:



Suitable for:


## Pressure switches

**3320218 PRESSOSTAT 230V 16(4)A**  
3 levels: 70/25 - 100/50 - 140/90



PRIMUS BLO001757300

**3320220 PRESSOSTAT 230V 16A**  
3 levels: 150/70 - 185/80 - 200/90



PRIMUS PRI340000076

PRIMUS PRI340000076


**3320219 PRESSOSTAT 250V 16A**  
3 levels: 150/80 - 240/100 - 285/160



PRIMUS PRI340000075


PRIMUS PRI340001075

**3320162 PRESSURE SWITCH 520/370-445/350-210/160**  
16A 250V  
for Washing machine (GRANDIMPIANTI) WM22000  
for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
XS22  
for Washing machine (PRIMUS) FS33 - FS40 - FS55  
XS22



PRIMUS PRI340000074


**3320158 PRESSURE SWITCH 87/35-310/265**  
for Washing machine (ASKO) WMC55 - WMP55  
for Washing machine (GRANDIMPIANTI) WFEC5  
for Washing machine (IMESA) LM5EGDP - LM5EGDV  
LM5EIDP - LM5EIDV  
for Washing machine (PRIMUS) PW5  
for Washing machine (WHIRLPOOL) AGB200/WP  
AGB201/WP - AGB202/WP - AGB203/WP



PRIMUS 8064275

PRIMUS 8064348

**3320209 SAFETY PRESSURE SWITCH**  
for Washing machine (ASKO) WMC55 - WMP55  
for Washing machine (GRANDIMPIANTI) WFEC5  
for Washing machine (IMESA) LM5EGDP - LM5EGDV  
LM5EIDP - LM5EIDV  
for Washing machine (PRIMUS) PW5  
for Washing machine (WHIRLPOOL) AGB200/WP  
AGB201/WP - AGB202/WP - AGB203/WP



PRIMUS 8061664

## Probes

**3397135 HUMIDITY PROBE**  
cable length 4400 mm - probe  $\varnothing$  27 mm  
for Dryer (POLIMATIC) T11 - T13 - T16 - T24 - T35  
T9  
for Dryer (PRIMUS) T11 - T13 - T16 - T24 - T35  
T9



PRIMUS 102456

**3397169 HUMIDITY PROBE**  
cable length 1250 mm  
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
ES5EIE  
for Dryer (PRIMUS) DAM5  
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE  
SE5IC - SE5IE



PRIMUS 8061855



Suitable for:

# PRIMUS Общепит



Suitable for:

## 3397170 PROBE

cable length 1340 mm  
 for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
 ES5EIE  
 for Dryer (PRIMUS) DAM5  
 for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
 AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE  
 SE5IC - SE5IE

# vsezip.ru

# +7(812)987-08-81




PRIMUS 8061900

## 3445255 TANK TEMPERATURE PROBE

cable length 2000 mm - bulb  $\varnothing$  6x60 mm  
 for Washing machine (POLIMATIC) P65 - P75  
 for Washing machine (PRIMUS) FS10 - FS16 - FS7  
 MB26 - MB33 - MB44 - MB66 - P6 - P7 - RS10  
 RS16 - RS22 - RS7  
 for Washing machine (WHIRLPOOL) WACS11 - WACS17  
 WACS28AE - WACS28AV - WACS35AE - WACS35AV  
 WACS46AE - WACS46AV - WACS6 - WACS7 - WACS70AE  
 WACS70AV - WACS8 - WAC11 - WAC17 - WAC23  
 WAC8

## 3744040 NUT M14

for Washing machine (PRIMUS) C6 - C8 - FS10 - FS16  
 FS6 - FS7 - MB16 - MB22 - MB33 - MB44 - MB66  
 P6 - P7 - RS16 - RS22 - RS6 - RS7  
 for Washing machine (WHIRLPOOL) LW100 - LW70  
 WACS11 - WACS16E - WACS17 - WACS28A - WACS35A  
 WACS46A - WACS6 - WACS7 - WACS70A - WACS8  
 WAC11 - WAC17 - WAC23 - WAC8



PRIMUS PRI340015019

PRIMUS PRI614000048

## 3744039 STUFFING GLAND $\varnothing$ 6 mm

for probe  
 for Washing machine (PRIMUS) FS10 - FS16 - FS7  
 MB26 - MB33 - MB44 - MB66 - P6 - P7 - RS10  
 RS16 - RS22 - RS7  
 for Washing machine (WHIRLPOOL) WACS11 - WACS17  
 WACS28AE - WACS28AV - WACS35AE - WACS35AV  
 WACS46AE - WACS46AV - WACS6 - WACS7 - WACS70AE  
 WACS70AV - WACS8 - WAC11 - WAC17 - WAC23  
 WAC8



PRIMUS PRI614000047



Suitable for:

**5045222 TEMPERATURE PROBE PT1000**

cable length 3 m  
for Dryer (PRIMUS) T24 - T9



PRIMUS 516092


# PRIMUS Общепит



Suitable for:

**3327171 THERMISTOR FOR TEMPERATURE PROBE**

for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA9  
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17  
SACE8 - SWE111 - SWE131 - SWE151



PRIMUS RSPM411758

PRIMUS RSPM414704

+7(812)987-08-81

## Pulleys

**3318010 BELT PULLEY**

for Dryer (PRIMUS) DAM/S9 - DA9 - D9  
for Dryer (WHIRLPOOL) SACE8 - SACE8C - SACE8T



PRIMUS RSP500269

PRIMUS RSP510158

**3062084 CLAMP**



PRIMUS RSP23748

**3062075 AXIS**

for pulley



PRIMUS RSP56461

PRIMUS RSP56461P

**3062082 WASHER**

for Dryer (DANUBE) DD8  
for Dryer (FAGOR) SE/7  
for Dryer (GIRBAU) SDE7  
for Dryer (IPSO) DD8  
for Dryer (PRIMUS) DAM/S9 - DA9 - D9  
for Dryer (WHIRLPOOL) SACE8 - SACE8T - SACE86  
SWE290 - SWE390 - SWE90 - SW291 - SW391 - SW91



PRIMUS RSP52549

**3318025 DOUBLE PULLEY  $\varnothing$  380 mm**

for Washing machine (PRIMUS) F10 - F6 - F7  
for Washing machine (WHIRLPOOL) LWS100 - LWS70



PRIMUS PRI60600001

**3318012 PULLEY  $\varnothing$  297 mm**

for washing machine drum  
for Washing machine (GRANDIMPIANTI) WFM6  
for Washing machine (PRIMUS) C6 - C8 - P6 - P7  
RS10 - RS6 - RS7  
for Washing machine (WHIRLPOOL) WACS6 - WACS7  
WAC11 - WAC8



PRIMUS PRI606000012





Suitable for:

PRIMUS Общепит



Suitable for:

**3318011 PULLEY  $\varnothing$  380 mm**

for washing machine drum  
for Washing machine (GRANDIMPIANTI) WFM6  
for Washing machine (PRIMUS) C6 - C8 - P6 - P7  
RS10 - RS6 - RS7  
for Washing machine (WHIRLPOOL) WACS6 - WACS7  
WAC11 - WAC8



PRIMUS 509819

vsezip.ru

+7(812)987-08-81

**Pumps**

**3122471 DRAIN PUMP FE30B4**

230V 50Hz 90W  
for Washing machine (GIRBAU) HS6008  
for Washing machine (GRANDIMPIANTI) WACS6 - WACS7  
for Washing machine (POLIMATIC) P65 - P75  
for Washing machine (PRIMUS) P6 - P7  
for Washing machine (WHIRLPOOL) WACS6 - WACS7



PRIMUS PRI333000017

**3353003 SLEEVE**

for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S  
for Washing machine (PRIMUS) C6 - C8 - P6 - P7  
for Washing machine (WHIRLPOOL) 016001-WACS6  
016071-WACS7



PRIMUS PRI503000045

**3122704 DRAIN PUMP HANNING DPS25-047**

30 W - 220 V - 50 Hz  
for Washing machine (IMESA) LM5EGDP - LM5EIDP  
PLM6  
for Washing machine (PRIMUS) PW5  
for Washing machine (WHIRLPOOL) AGB200/WP  
AGB202/WP - WACS5 - WACS5M - WES5GP - WES5IP



PRIMUS 8801166

PRIMUS 8801263



Suitable for:

# PRIMUS Общепит



Suitable for:

## Rating plates

### +7(812)987-08-81

### 3786411 BLACK PVC PANEL

for Dryer (ASKO) TDC44 - TD33  
 for Dryer (IMESA) ES5  
 for Dryer (PRIMUS) DAM5  
 for Dryer (WHIRLPOOL) AGB204 - AGB205 - AGB206  
 AGB207 - SACE5  
 for Washing machine (ASKO) WMC55 - WMP55  
 for Washing machine (IMESA) LM5  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB200 - AGB201  
 AGB202 - AGB203



PRIMUS 806547869

### 7104437 CONTROL PANEL MEC5EC GREY

for Washing machine (PRIMUS) FS10 - FS6 - FS7  
 WACS8



PRIMUS 527273

### 3319643 UNIT DISPLAY KEYBOARD

for Dryer (ASKO) TDC44  
 for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
 ES5EIE  
 for Dryer (PRIMUS) DAM5  
 for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
 AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE  
 SE5IC - SE5IE  
 for Washing machine (ASKO) WMC55  
 for Washing machine (IMESA) LM5  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB200/WP  
 AGB201/WP - AGB202/WP - AGB203/WP



PRIMUS 8063991-33

### 3322329 UNIT DISPLAY KEYBOARD

for Dryer (ASKO) - Series ES5 - TDC44  
 for Dryer (PRIMUS) DAM5  
 for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
 AGB206/WP - AGB207/WP  
 for Washing machine (ASKO) WMC55  
 for Washing machine (IMESA) LM5EGDP - LM5EGDV  
 LM5EIDP - LM5EIDV  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB200/WP  
 AGB201/WP - AGB202/WP - AGB203/WP - WES5GP  
 WES5GV - WES5IP - WES5IV



PRIMUS 8063990-33

## Relays

### 3351055 RELAY LY2F

for Dryer (PRIMUS) DA11 - DA13 - DA17  
 for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17



PRIMUS RSPM412534

PRIMUS RSP412534



Suitable for:

PRIMUS **ЗПИП** общепит




Suitable for:

## Reversing switches

### 3210023 REVERSING SWITCH PR1840

for Washing machine (PRIMUS) F10 - F6 - F7 - RS10  
RS16 - RS22 - RS7  
for Washing machine (WHIRLPOOL) WAC11 - WAC17  
WAC23 - WAC8



PRIMUS PRI343000057

+7(812)987-08-81

## Rinse aid containers and accessories

### 3066035 DETERGENT TANK

for Washing machine (IMESA) LM5EGDP - LM5EGDV  
LM5EIDP - LM5EIDV  
for Washing machine (PRIMUS) PW5  
for Washing machine (WHIRLPOOL) AGB200/WP  
AGB201/WP - AGB202/WP - AGB203/WP - WES5GP  
WES5GV - WES5IP - WES5IV



PRIMUS 8061661


### 3449274 SLEEVE

for detergent dispenser  
for Washing machine (IMESA) LM5EGDP - LM5EGDV  
LM5EIDP - LM5EIDV  
for Washing machine (WHIRLPOOL) AGB200/WP  
AGB201/WP - AGB202/WP - AGB203/WP - WES5GP  
WES5GV - WES5IP - WES5IV



PRIMUS 8061628

### 3066044 DETERGENT TANK




PRIMUS 8061630

### 3066046 EXTERNAL TANK



PRIMUS PRI505040027

### 3066043 INTERNAL DETERGENT TANK



PRIMUS 505041027



Suitable for:

**3066037 LID FOR PRODUCT DISPENSER**


for Washing machine (PRIMUS) FS10 - FS16 - FS7  
RS10 - RS16 - RS22 - RS7  
for Washing machine (WHIRLPOOL) 016002-WACS8  
016003-WACS11 - 016004-WACS17 - 016013-WAC8  
016014-WAC11 - 016015-WAC17 - 016016-WAC23



PRIMUS PRI505038027

**3066032 PRODUCT TANK**


for Washing machine (PRIMUS) P6 - P7  
for Washing machine (WHIRLPOOL) 016001-WACS6  
016071-WACS7



PRIMUS BLO003999400

**3066038 CONTAINER PLATE**

for Washing machine (PRIMUS) P6 - P7  
for Washing machine (WHIRLPOOL) 016001-WACS6  
016071-WACS7



PRIMUS 500099

**3528065 SCREW M4x12 FOR HANDLE**



PRIMUS 309933240412

# PRIMUS



Suitable for:

**3066034 WASHING TANK**

for Washing machine (PRIMUS) FS22 - FS33 - FS40  
FS55  
for Washing machine (WHIRLPOOL) 016005-WACS23  
016006-WACS23V - 016007-WACS35  
016008-WACS35V - 016009-WACS42  
016010-WACS42V - 016011-WACS55  
016012-WACS55V



PRIMUS 321848223000

**3242623 CONTAINER HANDLE**

for Washing machine (GRANDIMPIANTI) WFM11 - WFM6  
WFM8  
for Washing machine (PRIMUS) F5 - P5 - P6 - P7  
for Washing machine (WHIRLPOOL) LWS50 - LWS51M  
WACS6 - WACS7



PRIMUS 101161

**3066039 CONTAINER SUPPORT PLATE**

for Washing machine (PRIMUS) P6 - P7  
for Washing machine (WHIRLPOOL) 016001-WACS6  
016071-WACS7



PRIMUS 500100

**3353002 SLEEVE**

for product dispenser  
for Washing machine (GRANDIMPIANTI) WFM6  
for Washing machine (PRIMUS) F5 - P5 - P6 - P7  
for Washing machine (WHIRLPOOL) LWS50 - LWS51M  
016001-WACS6 - 016071-WACS7



PRIMUS BLO002319100

## Rotary switches

**3057310 POTENTIOMETER 120/240V**  
50/60 Hz - 2.5W



PRIMUS RSP431353

**3057309 TEMPERATURE SELECTOR SWITCH**  
25A 240V



PRIMUS RSP61512

**3057287 VIBRATION SELECTOR SWITCH MOD. 63.731**

5A-250V  
for Washing machine (GIRBAU) AS26 - AS33 - AS44  
AS66 - WFM33 - WFM40 - WFM55  
for Washing machine (PRIMUS) MB16 - MB26 - MB33  
MB44 - MB66  
for Washing machine (WHIRLPOOL) WACS16AE - WACS28  
WACS28AE - WACS28AV - WACS35 - WACS35AE  
WACS35AV - WACS46 - WACS46AE - WACS46AV  
WACS70 - WACS70AE - WACS70AV



PRIMUS PRI345000068

## Sensors

**7104462 INFRARED CELL**  
for Dryer (PRIMUS) SWE140



PRIMUS RSP56231

## Shock absorbers

**3007023 COMPLETE SHOCK ABSORBER TYPE 006**  
for Washing machine (GRANDIMPIANTI) WFM11 - WFM18  
for Washing machine (PRIMUS) FS10 - FS16 - FS7  
for Washing machine (WHIRLPOOL) WACS11 - WACS17  
WACS8



PRIMUS 510899

**3007026 RING FOR SHOCK ABSORBER**  
for shock absorber



PRIMUS PRI611007025

PRIMUS 611007025



Suitable for:

**3007025 RUBBER RING FOR SHOCK ABSORBER**  
for shock absorber



PRIMUS PRI611008025

PRIMUS 611008025

**3007038 SPRING FOR SHOCK ABSORBER**  
for 6-7 Kg yellow  
ø external 38-49 mm - ø internal 28-38 mm  
length 138 mm - ø thread 5 mm



PRIMUS PRI611029025

**3002003 ELASTIC RING FOR SHOCK ABSORBER ø 55 mm**  
ø 55 mm - height 30 mm  
for Dryer (GRANDIMPIANTI) CE10 - CE15



PRIMUS NYB489624541

**3007037 SHOCK ABSORBER COMPLETE TYPE 006 51/09**  
total length 360 mm



PRIMUS 517895

**3007025 RUBBER RING FOR SHOCK ABSORBER**  
for shock absorber



PRIMUS PRI611008025

PRIMUS 611008025

**PRIMUS** vsezip.ru  
Общепит

Suitable for:

**3007027 SHOCK ABSORBER SPRING**  
length 135 mm - ø 38-27 mm



+7(812)987-08-81

PRIMUS PRI611028025

**3007030 WASHER ø 35 mm**



PRIMUS PRI611009025

**3007026 RING FOR SHOCK ABSORBER**  
for shock absorber



PRIMUS PRI611007025

PRIMUS 611007025

**3007027 SHOCK ABSORBER SPRING**  
length 135 mm - ø 38-27 mm



PRIMUS PRI611028025





Suitable for:

**3007038 SPRING FOR SHOCK ABSORBER**  
for 6-7 Kg yellow  
ø external 38-49 mm - ø internal 28-38 mm  
length 138 mm - ø thread 5 mm




PRIMUS PRI611029025

**3007035 SHOCK ABSORBER R1064 B10C08**  
overall length 395 mm



PRIMUS 326270001064

**3007010 SHOCK ABSORBER TYP 012 140N**  
for Washing machine (DANUBE) GF10 - GF15 - GF18  
GF8  
for Washing machine (GRANDIMPIANTI) WFEC11  
WFEC18 - WFEC8 - WFM11 - WFM18 - WFM6 - WFM6S  
for Washing machine (IPSO) HF150 - HF185 - HW131  
HW164 - HW64 - HW72 - HW75 - HW94  
for Washing machine (PRIMUS) FS10 - FS7 - P6 - P7  
for Washing machine (WHIRLPOOL) WACS11 - WACS6  
WACS7 - WACS8



PRIMUS PRI611000025

PRIMUS 611000025


**PRIMUS** Общепит

Suitable for:

**3007030 WASHER ø 35 mm**

vsezip.ru

+7(812)987-08-81



PRIMUS PRI611009025

**3007013 SHOCK ABSORBER SPRING TYP006**  
overall length 355 mm  
for Washing machine (DANUBE) GF10 - GF15 - GF6  
GF8 - HF65 - HF76 - HF95  
for Washing machine (GRANDIMPIANTI) WFEC11  
WFEC18 - WFEC8 - WFM11 - WFM18  
for Washing machine (IPSO) HC100 - HC135 - HC165  
HC60 - HC65 - HC75 - HF110 - HF132 - HF165  
HM165 - HW131 - HW164 - HW55 - HW64 - HW72  
HW75 - HW94  
for Washing machine (PRIMUS) FS10 - FS16 - FS7  
for Washing machine (WHIRLPOOL) WACS11 - WACS17  
WACS8



PRIMUS PRI611001025

**5043707 BUSHING FOR SHOCK ABSORBERS**  
for WASHING MACHINE WHIRLPOOL LWS220



PRIMUS 223102100515





Suitable for:

**3242506 PIN BUSHING FOR DOOR HANDLE**

ø external 20 mm - ø internal 14 - height 20 mm  
for Washing machine (GRANDIMPIANTI) WFM33 - WFM40  
WFM55  
for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS 323622641243

**5043706 SPRING HOLDER HOSE**

for Washing machine (PRIMUS) F22  
for Washing machine (WHIRLPOOL) LWS220



PRIMUS 223102100714

**5050500 SHOCK ABSORBER TYPE 012 250N**

distance between holes 183 mm closed  
for Washing machine (FAGOR) LA-25M



PRIMUS 326269185250

# PRIMUS Общепит



Suitable for:

**7102075 PLIERS 155x36 mm**

for Washing machine (PRIMUS) F22 - F23  
for Washing machine (WHIRLPOOL) WACS23



PRIMUS 223102100314

## Sleeves

**3248145 DRAIN ELECTROPUMP COUPLING**

for Washing machine (POLIMATIC) P65 - P75  
for Washing machine (PRIMUS) P6 - P7



PRIMUS 521550

**3248147 DRAIN VALVE COUPLING**

ø external 83 mm  
for Washing machine (GRANDIMPIANTI) WFM33 - WFM40  
WFM55  
for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS 273238425503

7(812)987-08-81





Suitable for:

# PRIMUS Общепит



Suitable for:

## 3248146 SIPHON FOR DETERGENT TANK

for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S  
for Washing machine (POLIMATIC) P65 - P75  
for Washing machine (PRIMUS) P6 - P7

# vsezip.ru

# +7(812)987-08-81



PRIMUS 102341

## 3353004 SLEEVE

for product dispenser  
for Washing machine (GRANDIMPIANTI) WR11 - WR18  
WR24 - WR37 - WR8  
for Washing machine (PRIMUS) RS10 - RS16 - RS22  
RS7  
for Washing machine (WHIRLPOOL) 016013-WAC8  
016014-WAC11 - 016015-WAC17 - 016016-WAC23



PRIMUS PRI540000031

## 3394333 HOSE CLAMP $\varnothing$ 90-110 mm

for Washing machine (GRANDIMPIANTI) WR11 - WR18  
WR24 - WR37 - WR8  
for Washing machine (PRIMUS) RS10 - RS16 - RS22  
RS7  
for Washing machine (WHIRLPOOL) WAC11 - WAC17  
WAC23 - WAC8



PRIMUS PRI240000005

## Solenoid valves

### 3120297 SOLENOID VALVE 230V $\varnothing$ 10 mm

solenoid valve 90° - 230V 50Hz - max 90°C  
inlet 3/4" -dual outlet  $\varnothing$  10 mm  
with inlet flowrate reducer  
for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S  
for Washing machine (POLIMATIC) P65 - P75  
for Washing machine (PRIMUS) P6 - P7

### 3120298 SOLENOID VALVE 230V $\varnothing$ 10 mm

solenoid valve 90° - 230V 50Hz - max 90°C  
inlet 3/4" - triple outlet  $\varnothing$  10 mm  
with brown inlet flowrate reducer  
for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S  
for Washing machine (POLIMATIC) P65 - P75  
for Washing machine (PRIMUS) P6 - P7



PRIMUS 101834



PRIMUS 101832



Suitable for:

# PRIMUS Общепит



Suitable for:

## 3120166 SOLENOID VALVE 263A 220/240V ø 14 mm

solenoid valve 90° - 220/240V 50/60Hz - max 90°C  
 inlet 3/4" - triple outlet ø 14 mm  
 for Washing machine (GRANDIMPIANTI) WFM33 - WFM40  
 WFM55 - WR11 - WR18 - WR24 - WR26 - WR37 - WR48  
 for Washing machine (IMESA) RS10 - RS16 - RS22  
 RS7  
 for Washing machine (POLIMATIC) RS10 - RS35 - RS6  
 RS7  
 for Washing machine (PRIMUS) FS10 - FS6 - FS7  
 PS7 - RS10 - RS35 - RS6 - RS7  
 for Washing machine (WHIRLPOOL) WACS11 - WACS17  
 WACS23 - WACS6 - WACS7 - WACS8 - WAC11 - WAC17  
 WAC23 - WAC8

# vsezip.ru

# (812)987-08-81




PRIMUS PRI340030038

PRIMUS 101832

## Sparking plugs

### 3806012 IGNITION WITH BRACKET



PRIMUS 510184

### 3806011 SPARKING PLUG

ø 9 x length 65 mm - bracket 50x22 mm



PRIMUS RSP70032801

### 3806014 SPARKING PLUG

ø 9x99 mm - flange 48x22 mm  
for Dryer (PRIMUS) T11 - T13 - T16



PRIMUS 357375100500

### 7104440 SPARKING PLUG

for DRIER PRIMUS SWE140 - D14



PRIMUS RSP55438

### 7104454 SPARKING PLUG SUPPORT

for DRIER SWE140/D14



PRIMUS RSPM402745

**3250228 SUSPENSION SPRING**  
overall length 150 mm -  $\varnothing$  30 mm



PRIMUS PRI61000056

**3250229 SUSPENSION SPRING**  
overall length 155 mm -  $\varnothing$  30 mm



PRIMUS PRI61100056

## Supports

**3391061 SPACER**



PRIMUS 509922

## Switches

**7104459 BIPOLAR REVERSING SWITCH**  
for DRIER PRIMUS T24




PRIMUS 100388

**5054351 BIPOLAR SWITCH**  
mounting hole 14x28 mm  
for DRIER PRIMUS T9-11-13




PRIMUS 506045

**3319640 DOOR OPENING SWITCH**  
for Washing machine (PRIMUS) P5  
for Washing machine (WHIRLPOOL) LWS51M



PRIMUS BLO0001726500

**3319641 SWITCH KNOB**  
for Washing machine (PRIMUS) P5  
for Washing machine (WHIRLPOOL) LWS51M



PRIMUS BLO0003851200

PRIMUS BLO0003851203

**5048146 FULL CONTROL KEYBOARD GRAPHITRONIC**  
for Washing machine (PRIMUS) FS16 - FS23 - FS33  
FS40 - FS55




PRIMUS 520681



Suitable for:

**3319590 PUSH-BUTTON PANEL 6 BUTTONS**  
for Washing machine (PRIMUS) P5  
for Washing machine (WHIRLPOOL) LWS51M




PRIMUS BLO0001725800

**5009287 PUSH-BUTTON PANEL 6 BUTTONS**  
for WASHING MACHINE PRIMUS WACS8-FS6-FS7-FS10-W10



PRIMUS PRI348011091

**3319596 START/STOP SWITCH - 4 FASTON**  
for Washing machine (PRIMUS) P6 - P7  
for Washing machine (WHIRLPOOL) WACS6 - WACS7



PRIMUS 100195

**5041498 STOP BUTTON**  
for WASHING MACHINE GRANDIMPIANTI WFP120-AS26-AS33-AS44-AS66  
for WASHING MACHINE PRIMUS MB26-MB33-MB44-MB66-FS16  
for WHIRLPOOL WASHING MACHINE WACS28AE-WACS28AV-WACS35AE-WACS35AV-WACS46AE-WACS46AV-WACS70AE-WACS70AV  
for DRIER PRIMUS T24



PRIMUS 102259

# PRIMUS Общепит




Suitable for:

**3319591 PUSH-BUTTON KNOB**  
for Washing machine (PRIMUS) P5  
for Washing machine (WHIRLPOOL) LWS51M




PRIMUS BLO0003852203

**3319598 START POWER SWITCH**  
for Dryer (PRIMUS) DAM9 - DA9  
for Dryer (WHIRLPOOL) SACE8  
for Washing machine (PRIMUS) P5




PRIMUS RSP55882

**3319597 SEALING CAP**  
for switch  
for Washing machine (PRIMUS) P6 - P7  
for Washing machine (WHIRLPOOL) WACS6 - WACS7



PRIMUS PRI543000003

**3319642 SWITCH CASE**  
for Dryer (PRIMUS) T24  
for Washing machine (GRANDIMPIANTI) AS26 - AS33-AS44 - AS66 - WFP120  
for Washing machine (PRIMUS) FS16 - MB26 - MB33-MB44 - MB66  
for Washing machine (WHIRLPOOL) WACS28AE WACS28AV - WACS35AE - WACS35AV - WACS46AE WACS46AV - WACS70AE - WACS70AV




PRIMUS 102260

+7(812)987-08-81

## 3319593 SWITCH 4591 W2 - START/STOP - 6 FASTONS


for Dryer (ASKO) TDC44  
 for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
 ES5EIE  
 for Dryer (PRIMUS) DAM5  
 for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
 AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE  
 SE5IC - SE5IE  
 for Washing machine (IMESA) LM5EGDP - LM5EGDV  
 LM5EIDP - LM5EIDV  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB200/WP  
 AGB201/WP - AGB202/WP - WACS5 - WACS5M  
 WES5GP - WES5GV - WES5IP



PRIMUS 8061875

## 3319600 PUSH-BUTTON SPRING

for Dryer (ASKO) TDC44  
 for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC  
 ES5EIE  
 for Dryer (PRIMUS) DAM5  
 for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP  
 AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE  
 SE5IE  
 for Washing machine (ASKO) WMC55  
 for Washing machine (IMESA) LM5EGDP - LM5EGDV  
 LM5EIDP - LM5EIDV  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB200/WP  
 AGB201/WP - AGB202/WP - AGB203/WP - WACS5  
 WACS5M - WES5GP - WES5GV - WES5IP - WES5IV



PRIMUS 8061857

## 5041503 WHITE BUTTON SWITCH 40x14 mm

snap-in  
 16A 3/4HP 125/250VAC  
 for DRIER PRIMUS SWE140-D14



PRIMUS RSPM406103

## 3319599 PUSH-BUTTON LAMP

for Dryer (ASKO) TDC44  
 for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC  
 ES5EIE  
 for Dryer (PRIMUS) DAM5  
 for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205  
 AGB205/WP - AGB206 - AGB206/WP - AGB207  
 AGB207/WP - SECE5 - SE5GC - SE5GE - SE5IC  
 SE5IE  
 for Washing machine (ASKO) WMC55  
 for Washing machine (IMESA) LM5 - LM5EGDP  
 LM5EGDV - LM5EIDP - LM5EIDV  
 for Washing machine (PRIMUS) PW5  
 for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP  
 AGB201 - AGB201/WP - AGB202 - AGB202/WP  
 AGB203 - AGB203/WP - WACS5 - WACS5M - WES5GP



PRIMUS 8064069



Suitable for:




Suitable for:

## Thermostats

**7104441 RANCO ADJUSTABLE THERMOSTAT 88°C±135°C**  
bulb ø 8x195 mm - capillary length 295 mm  
for Dryer (PRIMUS) D14 - SWE140

**7104463 THERMOSTAT PUSH-BUTTON**  
for Dryer (PRIMUS) D14 - SWE140

+7(812)987-08-81



PRIMUS RSPM400780

PRIMUS RSPM400777

**3444825 THERMOSTAT PSP01 230V 50Hz**  
frame dimensions 95x95 mm  
for Washing machine (POLIMATIC) FS33 - FS40 - FS55  
XS22  
for Washing machine (PRIMUS) FS33 - FS40 - FS55  
XS22

**3444006 THERMOSTAT TR2 0-210°C**  
D-shaped pin ø 6x4.6 mm  
capillary length 1000 mm - 15A 250V  
bulb ø 5x140 mm



PRIMUS 506500

PRIMUS GMP100021

**3444328 THERMOSTAT 30-40-60-90°C**  
4 set temperatures 30°-40°-60°-90°C  
capillary 1050 mm  
bulb ø 6x125 mm  
16A 250V  
for Washing machine (PRIMUS) RS10 - RS16 - RS22  
RS7  
for Washing machine (WHIRLPOOL) WAC11 - WAC17  
WAC23 - WAC8




PRIMUS PRI340001012

## Timers

**3446210 TIMER M460-G**  
1/3HP 240V 50Hz 25A

**3446211 TIMER M481**  
3/4HP 20/10A 125/250V 50Hz



PRIMUS RSP500400

PRIMUS RSP510525

PRIMUS RSPC70131801

PRIMUS RSPM412079

**3446196 TIMER 60 MINUTES - 24V**

for Dryer (GIRBAU) SE112  
 for Dryer (IPSO) DR25 - DR35  
 for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25 - D35  
 D55 - D77  
 for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17  
 SACE25 - SACE35 - SACE55 - SWE111 - SWE131  
 SWE151 - SWE251 - SWE351 - SWE551



PRIMUS RSPM412080

PRIMUS RSPM412080P



**3446194 60 MINUTE TIMER**

3/4 HF - 20/10 A - 125/250 V - 50 Hz  
 25 A - 250 V - 50Hz  
 for Dryer (PRIMUS) D25  
 for Dryer (WHIRLPOOL) SACE25



PRIMUS RSPM410903P

**Water tight seals**

**3453014 COUNTER-SEAL RING  $\varnothing$  75x58x7 mm**

for GRANDIMPIANTI WASHING MACHINE  
 WFEC18-WR18-WR26  
 for IPSO WASHING MACHINE HF145-HF176-HF205-HF150  
 HF185-HW131-HW164-WE110-WE132-WE165-WE176-WE234  
 WE181-WF135-WF165-WF150-WF185-WF235-WFF135-WFF165  
 WFF150-WFF185-WFF235



PRIMUS PRI530030013

**3453013 RETAINER RING  $\varnothing$  58x88x18 mm**

sealing ring:  
 internal  $\varnothing$  58 mm  
 external  $\varnothing$  88 mm  
 thickness 18 mm  
 for GRANDIMPIANTI WASHING MACHINE WFM18  
 for IPSO WASHING MACHINE HF110-HF132-HF165-HF145  
 HF176-HF205-HF234-HW131-HW164-WE110-WE132-WE165  
 WE176-WE234-WE181-WF135-WF165-WF150-WF185-WF235  
 WFF135-WFF165-WFF150-WFF185-WFF235



PRIMUS PRI530030012

**3453037 SEALING RING**



PRIMUS 8801211

**3453030 SEALING RING  $\varnothing$  40x68x12 mm**

sealing ring:  
 internal  $\varnothing$  40 mm  
 external  $\varnothing$  68 mm  
 thickness 12 mm  
 for GRANDIMPIANTI WASHING MACHINE  
 WFEC8-WFEC11-WR8  
 WR11-WFM6-WFM6S  
 for PRIMUS WASHING MACH. P6-P7-RS6-RS7-RS10-F6-C6  
 for POLIMATIC WASHING MACHINE P65-P75-RS6-RS7-RS10  
 for IPSO WASHING MACHINE HC60-HC65-HC75-HC100-HF55  
 HF65-HF75-HF95-HW64-HW72-HW94-WE55-WE73-WE95-WF65  
 WF75-WF100-WFF65-WFF75-WFF100  
 for IMESA WASHING MACHINE LK8



PRIMUS PRI53000012



Suitable for:

**3453005 SEALING RING  $\varnothing$  50x80x13 mm**

sealing ring:  
internal  $\varnothing$  50 mm  
external  $\varnothing$  80 mm  
thickness 13 mm  
for GRANDIMPIANTI WASHING MACHINE  
WFM8-WFM11-WR11  
WR18  
for PRIMUS WASHING MACHINE FS6-FS7-FS10-RS13  
for POLIMATIC WASHING MACHINE FS6-FS7-FS10-RS13



PRIMUS PRI530020012


**3453006 SEALING RING  $\varnothing$  60x88x18 mm**

sealing ring:  
internal  $\varnothing$  58 mm  
external  $\varnothing$  88 mm  
thickness 18 mm  
f/ GRANDIMPIANTI WASHING MACHINE  
WFM18-WFEC18-WR18  
WR26  
for PRIMUS WASHING MACHINE FS16-RS18-RS22  
for POLIMATIC WASHING MACHINE FS16-RS18-RS22  
for IPSO WASHING MACHINE HC135-HC165-HF234-WE181  
WE234



PRIMUS PRI530030012

**3786438 TANK SEALING GASKET**



PRIMUS BLO0008203000

**PRIMUS** Общепит



Suitable for:

**3453039 COUNTER-SEAL RING  $\varnothing$  50x70x5 mm**


for PRIMUS F7-F10-RS10-RS16  
for WHIRLPOOL LW100-LWS100-WAC11-WAC17



PRIMUS PRI530020013

**3063097 SEALING RING WITH GASKET**

dimensions 40x58x5 mm



PRIMUS PRI530001013

+7(812)987-08-81



# Зип Общепит

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.

+7(812)987-08-81



**LF SpA**  
via Voltri, 80 - 47522 Cesena (FC) ITALIA  
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10  
www.lfrcambi724.it - www.lfrcambi724.mobi  
info@lfrcambi.it  
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55  
www.lfspareparts724.com - www.lfspareparts724.mobi  
export@lfspareparts.com

## FRANCE



**EPGC Sas**  
13, Rue des Forts - 59960 Neuville en Ferrain  
Tél. +33 (0)3 20 25 06 21  
Fax +33 (0)3 20 25 34 12  
www.epgc.com  
www.epgc724.mobi  
epgc@epgc.com

## DEUTSCHLAND



**LF GmbH**  
Junkersstrasse, 1 - D-82178 Puchheim - München  
Tel. +49 89 89 45 78 66  
Fax +49 89 89 45 78 88  
www.lfersatzteile724.de  
www.lfersatzteile724.mobi  
info@lfersatzteile.de

## SCHWEIZ



**LF GmbH Verkaufsbüro**  
Sennweidstrasse, 45 - CH-6312 Steinhausen  
Tel. +41 (0)41 760 15 80-1  
Fax +41 (0)41 760 15 85  
www.lfersatzteile724.ch  
www.lfersatzteile724.mobi  
info@lfersatzteile.ch

## ESPAÑA



**LF Repuestos Horeca S.L.U.**  
Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo  
Tif. +34 91 477 91 00  
Fax +34 91 477 90 81  
www.lfrepuestos724.es  
www.lfrepuestos724.mobi  
info@lfrepuestos.es

## UNITED KINGDOM



**LF Spare Parts Ltd.**  
A10a Lakeside Business Park, Broadway Lane  
South Cerney, Gloucestershire GL7 5XL  
Tel. +44 (0)1285 86 16 25  
Fax +44 (0)1285 86 39 49  
www.lfspareparts724.co.uk  
www.lfspareparts724.mobi  
info@lfspareparts.co.uk

## RUSSIA



**000 LF**  
ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow  
Tel. +7 499 259 85 75  
Fax +7 495 725 26 53  
www.lfspareparts724.ru  
www.lfspareparts724.mobi  
info@lfspareparts.ru

## CHINA



**LF China**  
Room 102, House 8, Lane 725, Mao Tai Rd.  
Changning Dist. - 200336 Shanghai  
Tel. +86 (0)21 33 53 66 31  
Fax +86 (0)21 33 53 66 32  
www.lfspareparts724.com  
www.lfspareparts724.mobi  
china@lfspareparts.com