

Зип Общепит

vsezip.ru

+7(812)987-08-81




**190FAD**

**Edition 20120112-**

Зип Общепит

vsezip.ru


+7(812)987-08-81



Зип Общепит

vsezip.ru


+7(812)987-08-81



Зип Общепит

vsezip.ru

+7(812)987-08-81



Page	Pos	Code	Description	Info
002	001	3013171	KNOB Ø8	12/05/2011-
002	002	3014320	FLEXIBLE PIPE DN10 L=400	12/05/2011-
002	003	3014330	FLEXIBLE PIPE DN10 L=600	12/05/2011-
002	004	3059470	UPPER CONTROL BOARD	12/05/2011-
002	005	3064310	GAS CONTROL BOARD	12/05/2011-
002	006	36A2002	GRID	12/01/2012-
002	007	36Q0080	BICONE Ø 10X6.5	12/05/2011-
002	008	36Q0830	BICONE NUT Ø 10	12/05/2011-
002	009	36Q1000	CLOSING BICONE NUT Ø4	12/05/2011-
002	010	36Q1040	BICONE Ø4	12/05/2011-
002	011	32Z1520	VALVE MAGNET	12/05/2011-
003	001	3019380	BURNER Ø 110 7kW	15/01/2007-
003	002	3019390	BURNER CAP Ø 110 7kW	15/01/2007-
003	003	3120460	SEAL RING	15/01/2007-
003	004	3152040	RING "OR" Ø 47,35	15/01/2007-
003	005	3152370	RING "OR" Ø 34.65	15/01/2007-
003	006	3152550	RING "OR" Ø 6.0	15/01/2007-
003	007	31M6320	SCREW TCB	15/01/2007-
003	008	31V0241	PIVOT	15/01/2007-
003	009	31V0370	HOLE PLUG	15/01/2007-
003	010	33A0680	THERMOCOUPLE	15/01/2007-
003	011	33A1490	M8X1X600 PILOT PIPE	15/01/2007-
003	012	33A1920	PILOT BURNER BODY	15/01/2007-
003	013	34A2000	VENTURI Ø 14.5	15/01/2007-
003	014	34A2020	NOZZLE SUPP. CONNECT.	15/01/2007-
003	015	34A2071	BURNER SUPPORT	03/12/2009-
003	016	34A2381	PILOT BURNER SUPPORT	28/01/2010-
003	017	35X4371	PILOT PIPE	15/01/2007-
003	018	36Q0020	BICONE Ø 6 X 6.5	15/01/2007-
003	019	36Q0060	CLOSING BICONE NUT Ø 6	15/01/2007-
003	020	36Q0080	BICONE Ø 10X6.5	15/01/2007-
003	021	36Q0610	BICONE SCREW Ø10	15/01/2007-
003	022	36Q1000	CLOSING BICONE NUT Ø4	15/01/2007-
003	023	36Q1040	BICONE Ø4	15/01/2007-
003	024	36Q1620	BICONE SCREW M 12X1	15/01/2007-
003	025	36Q1630	BICONE Ø 8X6.5	15/01/2007-
003	026	6013761	BURNER SUPPORT	03/12/2009-
004	001	3057600	BURNER ASS. Y4Kw Ø80	01/03/2006-
004	002	3057610	BURNER CAP Ø80 4KW	01/03/2006-
004	003	3057620	VENTURI PIPE	01/03/2006-
004	004	3060930	PILOT PIPE	01/03/2006-
004	005	3120460	SEAL RING	01/03/2006-
004	006	3152040	RING "OR" Ø 47,35	01/03/2006-
004	007	3152370	RING "OR" Ø 34.65	01/03/2006-
004	008	3152550	RING "OR" Ø 6.0	01/03/2006-
004	009	31M6320	SCREW TCB	01/03/2006-
004	010	31V0370	HOLE PLUG	01/03/2006-
004	011	33A0680	THERMOCOUPLE M8X1X600	01/03/2006-
004	012	33A1920	PILOT BURNER BODY	01/03/2006-
004	013	34A2020	NOZZLE SUPP. CONNECT.	01/03/2006-
004	014	34A2071	BURNER SUPPORT	03/12/2009-

Page	Pos	Code	Description	Info
004	015	34A2381	PILOT BURNER SUPPORT	28/01/2010-
004	016	35X4361	PILOT PIPE	01/03/2006-
004	017	36Q0020	BICONE Ø 6 X 6.5	01/03/2006-
004	018	36Q0060	CLOSING BICONE NUT Ø 6	01/03/2006-
004	019	36Q0080	BICONE Ø 10 X 6.5	01/03/2006-
004	020	36Q0610	BICONE SCREW Ø10	01/03/2006-
004	021	36Q1000	CLOSING BICONE NUT Ø4	01/03/2006-
004	022	36Q1040	BICONE Ø4	01/03/2006-
004	023	36Q1620	BICONE SCREW M	01/03/2006-
004	024	36Q1630	12X1 BICONE Ø 8X6.5	01/03/2006-
004	025	6020730	BURNER SUPPORT	01/03/2006-