

Зип Общепит

vsezip.ru

+7(812)987-08-81




**PGA20**

**Edition 20011205-**

Зип Общепит

vsezip.ru

+7(812)987-08-81



Pos	Code	Description	Info
001	30T6470	BASE	01/01/1996-
002	3150410	"O" RING Ø 18.72	01/01/1996-
003	3170070	SPRING	01/01/1996-
004	31X0110	PIN	01/01/1996-
005	31X0150	PIN	01/01/1996-
006	32A1780	POWER SUPPLY CABLE	01/01/1996-
007	32D0680	CABLE CLAMP	01/01/1996-
008	32D0710	THREE-POLE CONNECTOR	01/01/1996-
009	32M1550	FAN	01/01/1996-
010	32M6870	FAN MOTOR	05/12/2001-
011	32M5140	PUMP	28/03/1997-
012	32W0990	BIPOLAR SWITCH	01/01/1996-
013	32Z1290	CONDENSER	01/01/1996-
014	32Z2750	COIL	01/01/1996-
015	32Z6920	RELAY	01/01/1996-
016	32Z6930	ENGINE CUTOUT	01/01/1996-
017	32Z3840	TIMER	01/01/1996-
018	32Z3890	EVAP.THERM.	01/01/1996-
019	32Z7450	CONTAINER. THERM.	01/01/1996-
020	3300300	JOINT	01/01/1996-
021	33A0180	FILTER	01/01/1996-
022	33A0510	DEFROST SOL. VALVE	01/01/1996-
023	33A1200	AUXIL.VALVE	01/01/1996-
024	33A2910	FILTER	01/01/1996-
025	33D0490	CAPACITY CTRL	01/01/1996-
026	33D1371	INLET WATER SOLENOID VALVE	01/01/1996-
027	33D1860	OVERFLOW	01/01/1996-
028	33M0590	IN LET COUPLING	10/02/1997-
029	33M1160	WATER WAY IN	01/01/1996-
030	33Q6300	MANIFOLD	01/01/1996-
031	33Q6310	MANIFOLD	01/01/1996-
032	33T1890	JET	01/01/1996-
033	3400010	SCOOP	01/01/1996-
034	34D2850	COMPRESSOR R22 (TN)	01/01/1996-
035	34D3070	EVAPORATOR	01/01/1996-
036	34D3480	CONDENSER	01/01/1996-
037	34D4660	MOTOR ASS.Y	01/01/1996-
038	35C2170	REAR PANEL	01/01/1996-
039	3AA2980	LEFT SIDE	04/02/1998-
040	3AA2970	RIGHT SIDE	04/02/1998-
041	35G7640	COVER	01/01/1996-
042	35Q8890	PANEL-BOARD COVER	01/01/1996-
043	35V7541	DOOR SWAP	16/06/1997-
044	35V7710	PUMP SUPPORT	01/01/1996-
045	35V8300	PANEL BOARD	01/01/1996-
046	35W3620	FLUID TANK	01/01/1996-
047	36C0630	FOOT	01/01/1996-
048	36C1880	PROBE STOPPER	01/01/1996-
049	36D5670	SUPPORT	01/01/1996-
050	36Q1492	DROPS SEPARATOR	18/12/1997-
054	36Z0370	DOOR BACK PANEL	01/01/1996-

Pos	Code	Description	Info
055	36Z0420	DRAIN GUARD	01/01/1996-
056	36Z6661	TANK	19/12/1996-
057	36Z6680	GRID	01/01/1996-
058	36Z6700	DOOR	01/01/1996-
059	36Z6721	SPRAYER	19/01/1996-
060	36Z6740	COVER	01/01/1996-
061	37M1690	CONTROLS PLATE	01/01/1996-
062	37M6050	CONTROL PANEL	01/01/1996-
063	30A3870	FRAME	27/11/1996-
064	32Q1050	CABLE ASS.Y	01/01/1996-