

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
+ 1	CO4005		Foot
2	CO4559	(K300-330)	Bottom
2	CO4560	(K350-370)	Bottom
3	CO4561	(K300)	Bracket
4	CO4143	230V/1Ph/50-60Hz (K300)	Motor
4	CO4146	400V/3Ph/50-60Hz (K300)	Motor
4	CO4145	230V/1Ph/50-60Hz (K330-350-370)	Motor
4	CO4144	400V/3Ph/50-60Hz (K330-350-370)	Motor
5	CO4562		Bracket
+ 6	CO4563	TB2.34 510x10 (K300-330)	Belt
+ 6	CO4564	TB2.34 598x12 (K350-370)	Belt
7	CO4565		Plate
8	CO4566		Support
9	CO3971		Pivot
10	CO4061		Cam
11	CO4028		Washer
+ 13	CO3923	230V/1Ph/50-60Hz	Push button with card
+ 13	CO3924	400V/3Ph/50-60Hz	Push button with card
14	CO3943		Bracket
15	CO3942	8µF	Condenser
16	CO4567		Knob
17	CO3926	(K300-330) Assembly	Tool grinder
17	CO4568	(K350-370) Assembly	Tool grinder
18	CO4569	(K300-330)	Rod
18	CO4570	(K350-370)	Rod
+ 19	CO4571		Claw
+ 20	CO4572		Knob
21	CO4573	(K300-330)	Carriage
21	CO4574	(K350-370)	Carriage
22	CO4575		Shaft
23	CO4576		Support
24	CO4577	(K300)	Protection

+ : ricambio consigliato / spare part suggested

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
24	CO4578	(K330)	Protection	
24	CO4579	(K350)	Protection	
24	CO4580	(K370)	Protection	
25	CO4581		Knob	
26	CO4582	(K300)	Insert	
26	CO4583	(K330)	Insert	
26	CO4584	(K350)	Insert	
26	CO4585	(K370)	Insert	
27	CO4586	(K300)	Sail	
27	CO4587	(K330)	Sail	
27	CO4588	(K350)	Sail	
27	CO4589	(K370)	Sail	
+	28	CO4590	(K300-330)	Tie rod
+	28	CO4591	(K350-370)	Tie rod
	29	CO4003		Knob
	30	CO4556	(K300)	Support
	30	CO4002	(K330-350-370)	Support
	31	CO3995	(K300-330)	Pivot
	31	CO4592	(K350-370)	Pivot
+	32	CO3901	(K300-330)	Grinding wheel
+	32	CO0993	(K350-370)	Grinding wheel
	33	CO3999	(K300-330)	Pivot
	33	CO4593	(K350-370)	Pivot
	34	CO4000	(K300-330)	Pivot
	34	CO4594	(K350-370)	Pivot
	35	CO3996		Wheel pusher
+	36	CO3900	(K300-330)	Deburring wheel
+	36	CO0992	(K350-370)	Deburring wheel
	37	CO4595	(K300-330)	Knob
	38	CO3998	(K350-370)	Covering
	38	CO4596	(350-370)	Covering
	39	CO3997		Spring

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
40	CO4001	(K300-330)	Support
40	CO4597	(K350-370)	Support
41	CO4598	(K300-330)	Covering
41	CO4599	(K350-370)	Covering
42	CO4056		Spring
43	CO4618		Plate
44	CO4619		Support
45	CO4620	(K300-330)	Shaft
45	CO4621	(K350-370)	Shaft
46	CO4622		Support
47	CO4623		Spacer
48	CO4624		Spacer
49	CO4625	(K300-330)	Rod
49	CO4626	(K350-370)	Rod
50	CO4033	(K300)	Protection
50	CO4067	(K330)	Protection
50	CO4093	(K350)	Protection
50	CO4557	(K370)	Protection
51	CO4034	(K300)	Plate
51	CO4068	(K330)	Plate
51	CO4094	(K350)	Plate
51	CO4558	(K370)	Plate
52	CO4627		Pivot
53	CO4069		Pulley
54	SL0073	6004 ZZ	Bearing
55	CO4628		Spacer
56	CO4629	(K300-330)	Base
56	CO4630	(K350-370)	Base
57	CO4032	(K300)	Ring
57	CO4066	(K330)	Ring
57	CO4091	(K350)	Ring
57	CO4497	(K370)	Ring

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
58	CO3922	(K300)	Blade
58	CO4050	(K330)	Blade
58	CO2763	(K350)	Blade
58	CO2764	(K370)	Blade
59	CO4031	(K300)	Blade cover
59	CO4065	(K330)	Blade cover
59	CO4090	(K350)	Blade cover
59	CO4496	(K370)	Blade cover
60	CO3978		Pivot
61	CO4631		Pivot
62	CO4632		Rod
63	CO4633		Ram
64	CO4634		Spacer
65	CO4635		Holder
+ 66	CO4636		Protection
+ 67	CO4637		Knob
68	CO4638		Support
69	CO4639	(K300-330)	Salami carriage
69	CO4640	(K350-370)	Salami carriage
70	CO4641		Handle
71	CO4642		Cam
72	CO4643		Ring
73	CO4680	626 ZZ	Bearing
74	CO4644		Rod
75	CO4645		Plate
76	CO4646		Bush
77	CO4647		Spring
78	CO4648	(K300-330)	Rod
78	CO4649	(K350-370)	Rod
79	CO4650	(K300-330)	Plate
79	CO4651	(K350-370)	Plate
80	CO4652		Pivot

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
81	CO4681	608 ZZ	Bearing
82	CO4653		Support
83	CO4654		Bracket
84	CO4800	(K300-330)	Plate
84	CO4655	(K350-370)	Plate
85	CO4656		Spacer
86	CO4657		Pad
87	CO4658		Pad
88	CO4659		Bush
89	CO4660		Lever
90	CO4661		Pivot
91	CO4662	(K300-330)	Rod
91	CO4663	(K350-370)	Rod
+ 92	CO4016		Handle
93	CO4664		Spacer
94	CO4665	(K300-330)	Carriage
94	CO4666	(K350-370)	Carriage
95	CO4667		Pivot
96	CO4668		Ram
97	CO4669	(K300-330)	Carriage
97	CO4670	(K350-370)	Carriage
98	CO4671		Bush
99	CO4672		Protection
100	CO4673	(K300-330)	Support
101	CO4674	(K350-370)	Support
102	CO4675	(K300-330) Assembly	Salami carriage
102	CO4676	(K350-370) Assembly	Salami carriage
103	CO4677	(K300-330) Assembly	Meat carriage
103	CO4678	(K350-370) Assembly	Meat carriage
104	SL0075	ø20	Seeger
105	SL2056	ø42	Seeger
108	CO0415		Pivot



K/300 - K/330 - K/350 - K/370	T0001	00
-------------------------------	--------------	-----------

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
109	SL0271	608H ZZ	Bearing
124	CO4802	Assembly	Holder

+7(812)987-08-81

