

Зип Общежит

LISTA RICAMBI IMPASTATRICI IBM-IBT

RIF.	ITALIANO	INGLESE	CODICE						
	DESCRIZIONE	DESCRIPTION	IBM 5	IBM 10	IBM/IBT 15	IBM/IBT 20	IBM/IBT 30	IBM/IBT 40	IBM/IBT 50
1	TELAIO IMPASTATRICE	MIXER FRAME	7T010025	7T010025	7T010000	7T010000	7T010010	7T010020	7T010020
2	PANNELLO POSTERIORE	BACK PANEL	4P040558	4P040558	4P040555	4P040555	4P040556	4P040557	4P040557
3	COPERCHIO SUPERIORE	TOP LID	4P040550	4P040550	4P040550	4P040550	4P040551	4P040552	4P040552
4	CUSCINETTO SCHERMATO	BEARINGS	5C030012	5C030012	5C030012	5C030012	5C030012	5C030012	5C030012
5	VASCA	EXTRACTABLE BOWL	5V010512	5V010510	5V010514	5V010505	5V010506	5V010507	5V010508
6	SUPPORTO VASCA	BOWL SUPPORT	7A010520	7A010520	7A010520	7A010520	7A010509	7A010509	7A010510
7	VITE T.E.	T.E. SCREW	5V500002	5V500002	5V500002	5V500002	5V500002	5V500002	5V500002
8	CHIAVETTA	KEY	-	-	5L500039	5L500039	5L500039	5L500039	5L500039
9	CORONA DENTATA 3/8S	RING GEAR	5C030502	5C030502	5C030501	5C030501	5C030500	5C030500	5C030500
10	MOZZO CORONA	HUB CROWN	-	-	4F050010	4F050010	4F050010	4F050010	4F050015
11	RONDELLA PIANA	FLAT WASHER	-	-	5R500020	5R500020	5R500020	5R500020	5R500020
12	VITE M8	M8 SCREW	-	-	5V500057	5V500057	5V500057	5V500057	5V500057
13	CATENA SUPPORTO VASCA	BOWL SUPPORT CHAIN	5C020109	5C020109	5C020100	5C020100	5C020101	5C020102	5C020102
14	SUPPORTO SPIRALE	SPIRAL SUPPORT	3S010100	3S010100	7S010000	7S010000	7S010001	7S010002	7S010001
15/A	CUSCINETTO SCHERMATO	BEARINGS	5C030014	5C030014	5C030011	5C030011	5C030013	5C030013	5C030013
15/B	CUSCINETTO SCHERMATO	BEARINGS	5C030014	5C030014	5C030010	5C030010	5C030011	5C030011	5C030011
16	RONDELLA PIANA	FLAT WASHER	-	-	5R500027	5R500027	5R500020	5R500020	5R500020
17	VITE T.E.	T.E. SCREW	-	-	5V500003	5V500003	5V500057	5V500057	5V500057
18	VITE T.C.B. CROCE	CROSS T.E. SCREW	5V500499	5V500499	5V500499	5V500499	5V500499	5V500499	5V500499
19	CHIAVETTA	KEY	-	-	5L500035	5L500035	5L500035	5L500035	5L500035
20	SPIRALE	SPIRAL	5S080004	5S080004	5S080000	5S080000	5S080001	5S080001	5S080003
21	ASTA SPACCAPASTA	DOUGH BREAKER	4S010503	4S010503	4S010500	4S010500	4S010501	4S010502	4S010502
22	CATENA SPIRALE	SPIRAL CHAIN	5C020110	5C020110	5C020107	5C020105	5C020105	5C020107	5C020107
23	SUPPORTO UCF	UCF SUPPORT	5S030009	5S030009	5S030010	5S030010	5S030010	5S030010	5S030010
24	PIGNONE SUP.ALB. TRASM.	SUP. PINION, TRANSM. SHAFT	5P030009	5P030009	5P030000	5P030000	5P030001	5P030001	5P030001
25	ALBERO DI TRASMISSIONE	TRANSMISSION SHAFT	3A050514	3A050514	3A050510	3A050510	3A050511	3A050513	3A050513
26	PIGNONE INF.ALB. TRASM.	INF. PINION TRANSM. SHAFT	5P030008	5P030008	5P030005	5P030005	5P030006	5P030006	5P030006
27	SPINA ELAST. TIPO PESAN.	ELASTIC PLUG, HEAVY TYPE	5G510002	5G510002	5S100101	5S100101	5S100101	5S100101	5S100101
28	CHIAVETTA	KEY	5L500001	5L500001	5L500033	5L500033	5L500033	5L500033	5L500033
29/30	MOTORIDUTTORE MONOF.	SINGLE PHASE GEAR MOTOR	5M010010	5M010010	5M010501	5M010501	5M010506	5M010506	5M010511
29/30	MOTORIDUTTORE TRIF.	THREE PHASE GEAR MOTOR	-	-	5M010500	5M010500	5M010505	5M010505	5M010510
29/30	MOTORIDUTTORE TRIF. 2V	THREE PHASE GEAR MOTOR 2 SPEEDS	-	-	5M010502	5M010502	5M010507	5M010507	5M010512
31	INTERRUTTORE MONOFASE	SINGLE PHASE SWITCH	5I100040	5I100040	5I100040	5I100040	5I100040	5I100040	5I100040
31	INTERRUTTORE TRIFASE	THREE PHASE SWITCH	-	-	5I100030	5I100030	5I100030	5I100030	5I100030
32	TIMER	TIMER	5T010301	5T010301	5T010301	5T010301	5T010301	5T010301	5T010301
33	CAVO ALIM. MOTORE MONOF.	SINGLE PHASE GEAR CABLE	5C010001	5C010001	7C010023	7C010023	7C010023	7C010023	7C010023
33	CAVO ALIM. MOTORE TRIF.	THREE PHASE GEAR CABLE	-	-	7C010022	7C010022	7C010022	7C010022	7C010022
34	CAVO AZION. MICROSWIT.	MICROSWITCH CABLE	7C010027	7C010027	7C010024	7C010024	7C010024	7C010024	7C010024
35	CENTRALINA (per versione 2 velocità)	UNIT (FOR 2 SPEEDS VERSION)	-	-	5S010052	5S010052	5S010052	5S010052	5S010052
36	CAVO ALIM. LINEA	CABLE	-	-	INCORPORATO NELLE SCHELEA - included in the PCB				
37	GRIGLIA PROTEZIONE	PROTECTION GRID	5G080004	5G080004	5G080000	5G080000	5G080001	5G080002	5G080002
38	ASTA COPERCHIO	GRID SHAFT	3A010505	3A010505	3A010500	3A010500	3A010501	3A010502	3A010502
39	VITE T.E.	T.E. SCREW	5V500022	5V500022	5V500023	5V500023	5V500023	5V500023	5V500023
40	RONDELLA DENTELLATA	WASHER	5R500080	5R500080	5R500019	5R500019	5R500019	5R500019	5R500019
41	SUPPORTO MICROSWITCH	MICROSWITCH SUPPORT	4S060504	4S060504	4S060504	4S060504	4S060504	4S060504	4S060504
42	MICRO SWITCH	MICRO SWITCH	5M050500	5M050500	5M050500	5M050500	5M050500	5M050500	5M050500
43	PIGNONE SPIRALE	SPIRAL PINION	5P030007	5P030007	5P030010	5P030010	5P030011	5P030011	5P030011
44	LIMITATORE APERT. COP.	BRACKET	4L010025	4L010025	4L010026	4L010026	4L010027	4L010027	4L010027
45	VITE T.E.	T.E. SCREW	5V500054	5V500054	5V500054	5V500054	5V500054	5V500054	5V500054
47	PROTEZIONE	PROTECTION	4P020503	4P020503	4P020500	4P020500	4P020501	4P020501	4P020502

